

UniCool-Edge Air Conditioners

Installation and Operation Manual

Unit Models

20V1R1/20V1L1/40V1R3/40V1L3

Controller Model

ASMUC.6.AC/ASMUC.6.DC

This document contains proprietary information that is protected by copyright and other intellectual property laws. No part of this document may be reproduced, translated, or modified without the prior written consent of AIRSYS. The information contained in this document is subject to change without notice.

AIRSYS provides this material as is and makes no warranty of any kind, expressed or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. AIRSYS shall not be liable for errors contained herein or for incidental or consequential damages (including lost profits) in connection with the furnishing, performance, or use of this material whether based on warranty, contract, or other legal theory.

Designations used by other companies to distinguish their products are often claimed as trademarks. In this document, the product names appear in initial capital or all capital letters. Contact the appropriate companies for more information regarding trademarks and registration.

Copyright ©2012-2022 by AIRSYS

AIRSYS Cooling Technologies

support@air-sys.us

Table of Contents

1. Introduction	5
1.1 Using this Manual	6
1.2 Model Identification	8
1.3 Acronyms and Abbreviations	9
2. Product Overview	10
2.1 Free Cooling System	13
2.2 Adaptive Free Cooling	13
2.3 Mechanical Cooling System	13
2.4 Soft Start	13
2.5 The Control System (ASMUC.6 Controller)	13
2.6 Ease of Control and Configuration	14
2.7 Synchronized Cooling	14
2.8 Standalone Mode	14
2.9 Heat Load Matching	14
2.10 Turbo Boost	14
2.11 Quiet Mode	14
3. Installation	15
3.1 Installation Preparation	16
3.2 Delivery	16
3.3 Warranty	17
3.4 Moving the Unit	17
3.5 General Safety Rules	18
3.6 Required Materials	18
3.7 Physical Installation	21
3.8 Controller Box Installation	36
3.9 Complete Electrical Connections	40
3.10 Complete the Installation Checklist	45
3.11 System Commissioning	46
4. System Operation	58
4.1 User Interface Introduction	59
4.2 Navigating Menus	60
4.3 Main Screen	60
4.4 Program Menus	67
4.5 Step Test	68
4.6 Alarms	70
4.7 Exporting System History and Alarm Logs	73
4.8 Resetting Factory Defaults	74
4.9 Operational Logic	76

5.	System Parameters and Default Values	79
5.1	Step Test Menu Parameters	80
5.2	HVAC Config Menu Parameters	80
5.3	Control Configuration Menu Parameters	87
5.4	Accessing the System Menu	91
5.5	Accessing the Debug and Hardware Configuration Menus	91
6.	Preventative Maintenance	94
6.1	General Operation Check	95
6.2	Operation Checklist	98
7.	System Update	99
7.1	Local Software Update:	100
7.2	Remote Software Upgrade:	104
8.	Spare Parts	110
	Appendix A: Air Flange Drawing	115
	Appendix B: Wiring Diagrams	118

1. Introduction

Thank you for choosing a unit manufactured by AIRSYS.

UNICOOL-Edge, pioneering horizontal Packaged CRAC unit (P-CRAC) designed for edge computing application, featuring for its excellent performance in partitioning temperature field, forming cold and hot aisle, managing the airflow distribution, and enhancing the system efficiency.

Combining VFD technology with integrated free cooling function (economizer), UNICOOL-Edge has become a cutting-edge solution with of AIRSYS classic families.

The main components such as compressors, fans, motors, dampers, and other related items are all easily accessible and maintained from the front of the unit. The weight of each panel is less than 10kg (22lbs) for ease of removal and reinstatement.

In addition to having excellent energy efficiency, these systems are simple to operate, maintain, and service. The AIRSYS design team is committed to listening and responding to the customer community. As a result, these systems have continuously evolved with customer-defined features that have improved the overall quality and the user experience.

Usability features include:

- A functional step test that facilitates complete operational verification in less than 5 minutes
- Unobstructed access to all key components for Preventive Maintenance (PM) and servicing
- A high level of operational reliability via the built in Fail-Safe mode
- Completely selectable alarm relays (NC or NO) to enable the system to adapt to the customer's requirements
- In depth real-time system parameter readings available remotely and on site.
- Real-time power monitoring for individual units

1.1 Using this Manual

Read this manual carefully before attempting to install or start the unit. Retain this manual for reference for the entire operational life of the unit. This manual provides information on the following topics:

- Product overview
- Instructions for physical, and electrical installation of P-CRACs and the controller box
- Procedures for commissioning the system
- System operation, including system alarms, program menus, and advanced troubleshooting
- Preventive maintenance

This application is not intended for use by persons (including children) with reduced physical, sensory or mental capacities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of appliance by a person responsible for their safety.

This manual is part of unit and must be kept properly in order to prepare for future use. The use of high reliability component to ensure the quality of our products, through continuous investment to achieve technological and continuous improvement of products.

If the SUPPLY CORD or warning labels are damaged, it must be replaced by the manufacture, its service agent or similarly qualified person in order to avoid a hazard.

For safety and to achieve the highest levels of performance, always follow the warnings and cautions in this manual when handling and operating the AIRSYS unit.



Danger. Emphasizes hazardous conditions that could cause personal injury or death.









Warning. Indicates where the operator must proceed with caution to avoid personal injury or damage to property.



Important. Indicates technical information critical for proper installation or operation.

Table 1-1 lists symbols that may appear on the external packaging.

Table 1-1 Packaging Symbols

Symbol	Meaning	Symbol	Meaning
	THIS SIDE UP Shows the orientation of the unit.		NO HOOKS Do not use hooks to lift the packed unit.
	FRAGILE Handle with care.		KEEP AWAY FROM HEAT The unit must be kept away from heat sources.
	PROTECT AGAINST RAIN: The packaged unit must be stored in a dry place.		DO NOT STACK

1.2 Model Identification

Figure 1-1 Model Nomenclature

1	2	3	4	5	6	7	8	9	10	11	12
40	V	1	R3	M	R410	C	AC	.	X	X	X
1	40	Nominal kW. Total Cooling Capacity 20: 20kW @nominal condition 40: 40kW @nominal condition									
2	V	Compressor Type: V: Variable Capacity									
3	1	Compressor Qty									
4	R3	Mechanical Package Code R: Right Supply Package L: Left Supply Package 1 for 20kW, 3 for 40kW Supply position from indoor view. The number following "R" or L denotes package size. See mechanical drawing for detail.									
5	M	Design Control Configuration M: Designed for Multiple Unit Controller S: Designed for Single Controller									
6	R410	Refrigerant R410: R410a Refrigerant									
7	C	Custom Filters A: 208/230V 3PH 60Hz B: 208/230V 3PH 60Hz C: 460V 3PH 60Hz D: 380V 3PH 50Hz E: 220V 1PH 50Hz									
8	AC	AC: AC Powered EC Fan									
9	.										
10	X	Supply Fan Power X: Mesa Tan (Default) G: Light Gray									
11	X	Custom Coating X: Polyurethane Coated Panel and Frame + Coated Evaporator Coil (Default) C: Default + Coastal Condenser Coil Coating + Stainless Steel Fasteners E: Option C + Stainless Steel Panel and Frame									
12	X	Primary Power Supply X: MERV8 (Default) 2: MERV 13									

1.3 Acronyms and Abbreviations

Table 1-2 lists acronyms and abbreviations used in this manual.

Table 1-2 Packaging Symbols

Term	Meaning
A	Ampere, unit of electric current, or rate of flow of electricity
AAST	AIRSYS Authorized Service Technician
AC	Alternating Current
AFPD	Air Filter Protection Device
AUT/MAN	Automatic/Manual
BMS	Building Monitoring System
CFM	Cubic Feet per Minute
Com	Common
Comp	Compressor
Cond	Condenser
DC	Direct Current
Gen Run	Generator Run Signal
EC	Electronically Commutated (Refers to variable speed evaporator/supply fan)
Evap	Evaporator
FC	Free Cooling
HVAC	Heating, Ventilation, and Air Conditioning
I/O	Input/Output
LED	Light Emitting Diode
MC	Mechanical Cooling
N.C.	Normally Closed
N.O.	Normally Open
P-CRAC	Packaged Computer Room Air Conditioning
PSI	Pounds per Square Inch
PWM	Pulse Width Modulation
RoHS	Restriction of Hazardous Substances Directive
R/W	Read/Write
Temp	Temperature
VAC	AC Voltage
VDC	DC Voltage

2. Product Overview

The air conditioning system has three key components: the mechanical cooling system, the free cooling system (economizer), and the control system. The control system determines the unit's mode of operation: free cooling or mechanical cooling, as shown in Figure 2-1 and Figure 2-2




Figure 2-1 Mechanical Cooling Mode-Diagram Shown as Right Supply



Figure 2-2 Free Cooling Mode-Diagram Shown as Right Supply




Figure 2-3 Mechanical and Free Cooling Mode-Diagram Shown as Right Supply

2.1 Free Cooling System

When the operating conditions for free cooling are met, the control system switches the air damper to the free cooling position. Cooler air from outside is delivered to the shelter by the supply air fan. At the same time, hot air in the shelter is discharged to the outdoor environment.

2.2 Adaptive Free Cooling

With adaptive free cooling, the system will automatically learn and remember the optimal temperatures where free cooling can take over. Adaptive free cooling will continuously optimize toward free cooling hours with no human adjustment required. This is particularly valuable whenever the site heat load changes as the system will also adapt to find the new optimal free cooling setpoints.

2.3 Mechanical Cooling System

When the operating conditions for mechanical cooling are met, the control system switches the air damper to the mechanical cooling position. The compressor compresses the refrigerant gas and sends it to the condenser. The condenser is a heat exchanger, removing heat from the hot compressed gas and allowing it to condense into a liquid. The liquid refrigerant is then routed to the thermal expansion valve, which acts as a restriction device by forcing the refrigerant to go through a small hole. This causes the pressure to drop. Then the liquid refrigerant is routed to the evaporator. The evaporator is also a heat exchanger, absorbing heat from the indoor hot air causing the liquid refrigerant to change back into gas. The refrigerant gas is then routed back to the compressor to complete the cycle. The refrigerant is used repeatedly, absorbing heat from the indoor environment and discharging heat to the outdoor environment.

2.4 Soft Start

When mechanical cooling is requested, the compressor will ramp up its capacity and continuously modulate it to match the required site load. This minimizes mechanical stress upon startup, eliminates startup voltage spikes, and reduces unit noise level.

2.5 The Control System (ASMUC.6 Controller)

By default, the ASMUC.6 controller can control up to 6 AIRSYS Precision Cooling P-CRACs (16 with expansion module) organized in up to 4 zones. The setpoint for each zone can be adjusted independently.

The controller box is factory programmed with standard industry setpoints but can be configured on-site or remotely to meet specific needs. Settings are retained in the event of a power loss. In addition, all P-CRACs have integrated control modules that are the same as those in the controller box. If communication between the units and controller is lost, the units will cool independently using the last given controller settings and information from onboard temperature and humidity sensors.

2.6 Ease of Control and Configuration

The controller is controlled through the Programmable Graphical Display (PGD) interface. The PGD and button actions are explained in more detail starting on Page 52. Using the PGD interface, the user can:

- Check the status of the HVAC system, such as sensor readings and operating mode
- Change factory setpoints
- Place the system temporarily into comfort mode
- Review alarms and alarm history

Labeling on the outside of the controller box provides a convenient guide on how to access the most common functions. The same functions can be accessed remotely via an IP communication interface built into the controller. The units are also pre-wired to allow for a PGD to connect directly to the unit, allowing for testing and configuration directly from the unit.

2.7 Synchronized Cooling

When mechanical cooling is required to maintain the site temperature, all available units will run at low speed as opposed to one unit taking the full load. This increases overall system efficiency and reduces wear and tear on the compressor. If one of the units is taken offline, the others will adjust their speeds accordingly to maintain the site temperature.

2.8 Standalone Mode

The system can operate in fully functional Standalone Mode when communication is lost between HVAC and controller. This includes including free cooling, mechanical cooling, dehumidification, and heating. This eliminates the controller as a potential single point of failure for the HVAC system.

2.9 Heat Load Matching

The variable capacity units can adjust the compressor run speed to exactly match the heat load as opposed to cycling on and off to maintain a setpoint. Since most of the component stress occurs during startup and shutdown, heat load matching increases overall system reliability and efficiency.

2.10 Turbo Boost

In situations such as extreme outdoor temperature, the heat load of the building may exceed the nominal cooling capacity of the system. In those cases, Turbo Boost can automatically overdrive the units to provide up to 120% of the rated capacity at the cost of some efficiency.

2.11 Quiet Mode

Quiet mode reduces noise by 10-14 dBA by limiting the maximum speed that the compressor can run at. In doing so, the maximum cooling capacity will be reduced by ~15% and Turbo Boost will be disabled.

3. Installation

3.1 Installation Preparation

Unpack the unit carefully. Some parts are packed loosely and may move as the packaging is opened. Before discarding the box, check the packaging carefully for any parts or documents inside. Refer to Table 3-1 on Page 16 for the complete list of materials shipped with each unit.

Check that:

The supply voltage meets the requirements as designated: 190-507VAC,.

The install location is clean on the inside and free of excess dirt and dust.

- Minimum install clearances are met (see “Clearances” on Page 25).
- All installer provided items, listed in Table 4 on Page 17 are accounted for.

Installation and startup must be performed by an AIRSYS Authorized Service Technician (AAST). For more information about the AAST program, please contact:

AIRSYS Cooling Technologies

support@air-sys.us

855-874-5380



Danger. All the installation work must be done by professional technicians. Installation that does not comply with the instructions herein can result in the loss of warranty coverage. AIRSYS shall not be held liable for any damage caused to persons or objects due to incorrect installation or operation of the units.



Warning. All wiring must comply with the local safety standards and building codes under all circumstances.



Warning. Risk of electric shock can cause injury or death: disconnect all remote electric power supplies before installation.

When no longer in use, disposal of equipment and materials must be compliant with local laws and standards.

3.2 Delivery

When the units are delivered, be sure to inspect them to verify that they have not been damaged during transport. Also verify that all requested accessories listed on the purchase order have been included.



Important. If packages show any signs of shipping damage or potential shipping damage, it is very important to annotate shipping damage on the Bill of Lading prior to signing for the freight. To recover for any damage, please take detailed photographs of all the packaging before the external packaging is removed. Once detailed photos of the external packaging have been taken, then the external packaging may be removed so the items can be inspected further. Please document with photos any damage to the equipment that relates directly to the damage observed to the external packaging. Without the detailed photos, it will be very difficult to recover equipment loss.

3.3 Warranty

The warranty duration is 12 months from the date of installation. AIRSYS warrants that its products will be free from defects in materials and workmanship for a period of 12 months after installation.

The compressor is to be free from defects in material or workmanship for a period of 60 months from date of installation.



Important. For sites equipped with a generator, when the generator switches to the primary source of power, the instantaneous voltage may become lower. If this is the case, the compressor may run at a lower voltage which can decrease the compressor's working life. Make sure the Gen-Run signal input is connected which can protect the compressor. The warranty does not cover damage to the compressor caused by repetitive out of specification supply voltage during compressor operation.

AIRSYS will furnish free of charge replacement parts for any component failures that occur within the warranty period. Customer is responsible for the cost of shipment of replacement material from AIRSYS Cooling Technologies.

Note: Warranty assumes that an AAST performs the installation and submits the warranty registration card that accompanied the units in shipment. If the warranty registration card was not filled out and returned to the supplier, then the warranty will be assumed to expire 12 months from the date of shipment for all components except the compressor, which will be assumed to expire 60 months from date of shipment.

This warranty does not cover damage to the systems caused by misuse or abuse of the systems such as physical damage due to mishandling. The warranty does not cover damage caused by force majeure.



Important. Any mishandling of the equipment or modifications to the equipment, unless agreed upon in writing by AIRSYS, will void the warranty.

3.4 Moving the Unit

Forklifts are recommended for moving, loading, unloading, and positioning the P-CRAC for installation. If bands or ropes are used to create a sling, make sure that excessive force is not applied to the upper edges of the machines or the package to avoid cosmetic or material damage. When using spacing bars, protective materials are required around the units to prevent damage. To avoid damage to the units while moving or transporting, ensure the units always remain in the upright position.



Important. Shipping UniCool Edge on a building is not a function of Airsys and will rely completely on the design of the building/container/Shelter manufacturer.

Note:

1. The 40V1R(L)3 unit may not be compatible with pallet jacks due to low pallet height. Loading dock facilities or lift gate equipped vehicles are recommended when transporting the unit. A crane may be required to lift the unit due to the weight (1485 lb/675kg).
2. It is recommended that the building/container/shelter manufacturer to made concrete pad or stand to support the unit. (Refer to Table 3-6 for dimension and weight of each unit if stand is needed for installation.) The length and width of the stand cannot be smaller than the length and width of the unit

3.5 General Safety Rules



Danger. Do not carry out any operation on the machines if you do not have sufficient knowledge of the operating principles and have not taken all the precautions that permit the system to operate in safe conditions.



Warning. Work on the electric board only after verifying prime power is disconnected. Do not apply power to the machine with the covers removed.



Important. Before carrying out inspections, maintenance operations, and safety checks, follow all accident-prevention standards such as wearing protective goggles and gloves.

3.6 Required Materials

3.6.1 AIRSYS Supplied Materials

Table 3-1 lists all material supplied by AIRSYS. After opening the package, verify that all items are accounted for. If any material is missing, please contact an AIRSYS distribution center using the following information:

AIRSYS Cooling Technologies

Email: support@air-sys.us

Phone: 855-874-5380

Table 3-1 AIRSYS Provided Materials

Unit Assembly

Item	Part #	Qty	Description	Comments
1	N/A	1	Shipping list	
2	4070143620	1	Packaged Computer Room Air Conditioning	
3	N/A	1	Installation and Operation Manual	
4	7151011110	5	Sponge 2000*50*10mm (78 3/4* 2 * 3/8 inch)	
5	1060540600	2	Return Air Flame	
6	1060540590	2	Supply Air Flame	
7	8551016130	50	M5*16 screw	Replacement screws for P-CRAC access panels For supply air and return air flange installation.
8	N/A	50	Rubber gasket	To be used in conjunction with screws to protect painted finish on units
9	7151008920	10	CR Sponge 2000*20*3 (78 3/4 * 3/4 * 1/8 inch)	Shipped in the middle liner of the unit

Multi Unit Controller

Item	Part #	Qty	Item Description	Comments
1	2040310370	1	Controller box: ASMUC.6	Includes: 2 temperature sensors (Label: ST1, ST3) 1 humidity sensor (Label: SH).
2	N/A	1	Shipping list	
3	1170104800	1	Installation and Operation Manual	
4	8552600560	8	M4.2*25 Self-tapping screw	For controller box installation
5	8551016130	56	M5*16 screw	Replacement screws for WPU access panels For supply air and return air flange installation
6	1110212510	1	Product Warranty Registration Card	
7	1110212560	3	Compressor shipping bracket removal sticker	To ensure the removal of compressor brackets at startup
8	1050500720	2	Temperature sensor bracket	For mounting temperature sensors
9	8458716830	1	Box for outdoor temperature sensor	For mounting outdoor temperature sensor
10	8654009410 1021006350 1021006360	4	Spare breaker panel clip	For locking the breaker panel if necessary

3.6.2 Materials Supplied by Installer

Table 3-2 lists items required for installation that must be supplied by an AIRSYS Authorized Service Technician (AAST). The wire length and gauge depend on site-specific conditions. However, recommendations are provided.

Table 3-2 Installer Supplied Materials

No.	Item	Qty	Description	Comments
1	AC Power Supply Cable to P-CRACs	Same as number of units	1 set of two-wire cable per P-CRAC	Refer to Summary Electrical Ratings
3	DC Power Supply Cable to Controller Box	1	1 set of two-wire cable for P-CRAC controller box	Max current capacity 0.8A; 18AWG recommended
4	AC Circuit Breaker	Same as number of units	1 Breaker for each P- CRAC	Refer to Summary Electrical Ratings
6	DC Circuit Breaker for Controller	1	1 Breaker for the Controller	Max current capacity 0.8A
7	Communication Cable from Controller Box to P-CRAC	Same as number of units	1 Ethernet Cable per P-CRAC	The ethernet (CAT5/5E/6) cable should meet ANSI/TIA-568-B.2 standard

No.	Item	Qty	Description	Comments
8	Alarm Wiring Harness (Optional)	Up to 9	1 cable with 2 wires, length as needed	Alarm connection to controller box, 3 alarm inputs and 6 alarm outputs; all alarm connections are optional
9	Adhesive Tape	As needed	With single-sided adhesive	Used to line the return and supply air frames
10	Silicone Sealant	As needed	Commercial grade outdoor silicone sealant	
11	Nylon Zip-Tie	As needed	Nylon zip ties	For properly dressing cables and harnesses
12	Supply Air Grille	As needed		Built inside wall to facilitate air flow
13	Return Air Grille	As needed		Built inside wall to facilitate air flow
14	Mounting Hardware	As needed	Hardware for mounting unit to wall	Varies based on wall material and thickness
15	Neoprene Gasket	As needed	Provides airtight seal around return/exhaust & supply holes	Should be thick enough to accommodate the rough finish of the shelter exterior

3.6.3 Summary Electrical Ratings (Wire Sizing)

Table 3-3 UniCool Edge Electrical Ratings

Model	Circuit #1			
	6kW Electrical Heater		12kW Electrical Heater	
	MCA	MOP	MCA	MOP
20V1R(L)1MR410AAC	68	80	101	140
20V1R(L)1MR410BAC	39	45	58	80
20V1R(L)1MR410CAC	20	20	29	40
40V1R(L)3MR410BAC	59	70	78	100
40V1R(L)3MR410CAC	33	40	42	50

Table 3-4 Controller Electrical Ratings

Model	Power Source	48VDC	
		Max Power	Max Current
ASMUC.6.AC	120VAC	90W	0.75A
ASMUC.6.DC	24VDC/48VDC	30W	1.3A/0.6A

3.7 Physical Installation

To assist in the installation process, the following figure provide the unit dimensions to a tolerance of $\pm 1/16''$ (2 mm).




Figure 3-1 Physical Dimension (40V1R3)




Figure 3-2 Physical Dimension (40V1L3)




Figure 3-3 Physical Dimension (20V1R1)




Figure 3-4 Physical Dimension (20V1L1)

3.7.1 Installation Preparation



Important. It is the builder’s responsibility to create a concrete base or steel rail platform for the unit. The wall is not intended to hold the unit. Refer to Table 8 below for unit dimensions and weights by model number.

3.7.2 Clearances

The recommended clearances shown below should be adhered to when possible. Units will not be able to operate correctly if minimum clearances are not met.

Table 3-5 Installation Clearances

Clearance	Recommended	Comments
Front	160 in (4000 mm)	Clearance between unit and solid obstructions.
Side	25 in (600 mm)	Minimum spacing between unit and wall.
Side	50 in (1200 mm)	Minimum spacing between two units

Table 3-6 Dimensions and Weight by Model Number


	Model	20V1R(L)1	40V1R(L)3
Width	in (mm)	92-11/16(2355)	131-1/16 (3330)
Depth	in (mm)	51-3/16 (1300)	51-3/16 (1300)
Height	in (mm)	25-9/16 (650)	34-1/4 (870)
Weight	lbs (kg)	1102(500)	1488 (675)



Important. The wall selected for the unit must be strong enough to support both the static weight of the unit and the vibration of a unit under operation.


3.7.3 Openings in the Wall

Make openings for supply and return air and cable and bolt holes in the installation wall as shown in Figure 3-5. All dimensions are accurate to 1/16 in (2 mm).




Note: Looking from the outside

Figure 3-5 Openings and Holes in the Wall (40V1R3)




Note: Looking from the outside

Figure 3-6 Openings and Holes in the Wall (40V1L3)



Note: Looking from the outside

Figure 3-7 Openings and Holes in the Wall (20V1R1)



Note: Looking from the outside

Figure 3-8 Openings and Holes in the Wall (20V1L1)

3.7.4 Install CR Sponge

Apply 7151008920 CR sponge 2000*20*3 (78 3/4 * 3/4 * 1/8 inch) on the top panel of the unit. (This helps to reduce the vibration of the unit while operating). Refer to Figure 3-9 below.




Figure 3-9 Install CR-Sponge

3.7.5 Install Supply/Return Air Frame

Use 8551016130 M5*16 screw to install the supply air frame (1060540600) and return air frame (1060540590). Refer to Figure 3-10 below.




Figure 3-10 Install Supply/Return Air Frame

3.7.6 Install Weather Stripping

Before mounting the unit on the outside wall, fix neoprene weather stripping (installer provided) around the openings of the air supply and the air return to ensure an airtight closure, as shown in Figure 3-11.




Figure 3-11 Install Weather Stripping

3.7.7 Remove Wooden Pallet from P-CRAC

The P-CRAC is bolted to a wooden pallet to facilitate safe lifting and transport of the unit. Four bolts attach the pallet to the unit, as shown in Figure 3-12. The pallet frame is recessed under the P-CRAC to allow for easy installation while using a forklift. Before completing the mounting of the unit to the wall, remove the pallet by removing the four bolts.



Figure 3-12 Remove Wooden Pallet

3.7.8 Lift the Unit

There are 4 eye bolts on the top corner of the unit. Attach steel string and lift the unit as shown in Figure 3-13.




Figure 3-13 Lift the Unit




Figure 3-14 Center of Gravity 40V1R3





Figure 3-15 Center of Gravity 40V1L3




Figure 3-16 Center of Gravity 20V1R1

3.7.9 Position the Unit



Important. The unit is heavy. Exercise caution while putting the unit in place to prevent damage to the P-CRAC or personnel.

The unit must be installed in a level position. An inclination of more than 6-7 mm could cause the condensation tray to overflow (Figure 3-17)




Figure 3-17 Inclination of Mounted P-CRAC

Note: The 40V1R(L)3 requires equipment capable of lifting 1485 lbs (675 kg).

1. Attach a single mounting screw and adjust to ensure the unit is level.
2. After the unit is level, attach the remaining mounting screws.

3.7.10 Seal the Joints between P-CRACs and Wall

To prevent moisture from getting in and air leaking out, coat the joint between the rear panel of the unit and the wall with a layer of silicone sealant (installer provided, see Table 3-2, item 1) as shown in Figure 3-18.




Figure 3-18 Seal the Joints Between P-CRAC and Wall

3.7.11 Remove the Compressor Brackets

Open the front panel on the P-CRAC to locate the compressor. The two brackets at the base of the compressor are required for transport only. Loosen the four bolts, remove the two brackets, and then tighten the four bolts back down to the base of the compressor.



Figure 3-19 Remove Compressor Brackets

3.8 Controller Box Installation

Find a suitable location inside the shelter to mount the controller box. Mount the controller box so that the PGD is near the eye level of the intended operator.







Figure 3-20 Controller Box Dimensions

Table 3-7 Key Components in the Controller Box Assembly

Temperature Sensor	PGD Display	Humidity Sensor
		
Control Module		Input Breaker
		

3.8.1 Install Outdoor Temperature Sensor

The outdoor temperature sensor (ST3) that is connected to the controller box must be installed outside the shelter. Use the following steps to complete this task.

1. Select the wall where the WPU is mounted.
2. Drill a 1/2-inch diameter hole for the outdoor temperature sensor (ST3) through the shelter wall.



Figure 3-21 ST3 Through Wall

3. Open the controller box assembly and locate the outdoor temperature sensor (ST3) assembly.

4. Thread the outdoor temperature sensor through a port at the bottom of the controller box.



Figure 3-22 ST3 Through Bottom of Controller Box

5. Thread the outdoor temperature sensor from the controller box through the hole in the bottom of the box.
6. Secure the sensor to the bottom of the box with a nylon zip-tie.
7. Secure the box to the outside wall. Snap the sensor box cover in place and use sealant along the seam between the box and the wall.

Note: punching out the holes on the sides and the bottom of the sensor box is critical to allow proper airflow and drainage from rain and dew.




Figure 3-23 Ensure No Leakage



Important. Ensure no air leakage exists from inside the shelter to the box housing the outdoor temperature sensor. Any path whereby air could exit the shelter and arrive in the sensor box will adversely affect the outdoor temperature sensor reading.

3.8.2 Position the Humidity Sensor

Follow these steps to install the humidity sensor that is connected to the controller box:

1. Open the controller box assembly and locate the humidity sensor (SH) assembly.
2. Remove the cover of the humidity sensor, and then unfasten the harness from the sensor.
3. Thread the harness through the hole at the bottom or top of the controller box and reattach the sensor and then the cover.

Note: If building is not yet in its final, permanent location after mounting the controller, secure the humidity sensor under the controller box with tape to protect the sensor from vibration.




Figure 3-24 Position the Humidity Sensor

3.8.3 Position Indoor Temperature Sensor

The indoor temperature sensor (ST1) is located at the bottom of the controller box. The sensor monitors the shelter temperature to control the WPU operation. Slide the sensor through the port on the bottom left side of the controller box. Tighten the port cover to hold the sensor cable in place.




Figure 3-25 Position the Indoor Temperature Sensor

3.9 Complete Electrical Connections

3.9.1 Cautions



Danger. Only an authorized service technician should make the electrical connections to the WPU's and the controller box.



Important. The electrical wiring of the unit must comply with IEC standards or with appropriate national standards.



Danger. The power supply must be disconnected or turned off before working on the unit.



Important. Noncompliance with these instructions may cause damage to the WPU or the controller box. Not following instructions can void the warranty.



Important. No modification to the unit's electric circuit is allowed. If a change is required, it must be authorized by AIRSYS in writing.

3.9.2 Output Alarms

Output alarms are dry contract outputs from the ASMUC to a remote monitoring block/station. Consult the ASMUC wiring diagram in Appendix B for wiring locations.

3.9.2.1 High/Low Temp Alarm

A high temp alarm will trigger when the indoor temperature has exceeded the high temperature setpoint for at least 1 minute. The default high temp trigger is 18°F above the main setpoint and can be changed under "Alarms" in the HVAC Config menu. A low temp alarm will trigger when the indoor temperature has dropped below the low temperature alarm setpoint (default 32°F below setpoint). The default output setting is Normally Closed (NC), which can be changed to Normally Open (NO) in the "Alarms" menu under the HVAC Config Menu.

3.9.2.2 HVAC Alarms

An HVAC alarm indicates one or more major alarms that will prevent a unit from Mechanical Cooling. This includes:

- High and low refrigerant pressure (only affects mechanical cooling)
- Power loss
- Fan overload / airflow alarm
- Communication failure
- Failure of both indoor and backup indoor temperature sensors

The ASMUC.6 controller provides three dry contact outputs for HVAC fail alarms. If more connections are needed, multiple HVAC alarms may be wired in series if NC or in parallel if NO.

Note: The negative leads must be landed on the alarm common (Terminal 47).

3.9.2.3 Dirty Filter Alarm Output

This alarm will trigger when the filter of any unit connected to the controller is dirty and needs replacement. The alarm can be wired as either NO or NC. The default output setting is Normally Closed (NC), which can be changed to Normally Open (NO) in the "Alarms" menu under the Control Config Menu.

3.9.3 Input Alarms

Input Alarms are used to inform the ASMUC of an alarm that is present in the building and make the ASMUC behave accordingly.

Note: all inputs must be dry contact signals.

3.9.3.1 Smoke/Fire Alarm Input

This alarm input informs the controller that the smoke/fire detector has been triggered. All components will immediately shut down and outside air damper will fully close until alarm condition is removed. The default setting is Normally Closed (NC), which can be changed to Normally Open (NO) in the “Alarms” menu under the Control Config Menu.

This alarm input must be wired to an isolated output or a relay. Piggybacking with other devices may cause a false alarm.

Note: this is an input only and will not work as an output to a remote monitoring station.

3.9.3.2 Generator Run Input

This alarm input informs the controller that the generator is running. Outside air damper will fully close to prevent diesel fumes from entering the building and only one HVAC will be permitted to run at a time to minimize generator load. The default setting is Normally Open (NO), which can be changed to Normally Closed (NC) in the “Alarms” menu under the Control Config Menu.

AL*07 (Generator Run) will display if this input is triggered.

Optional: Enable the multiple compressors during generator run in the “Generator Run” section of the Unit Config menu.

3.9.3.3 DC Fail-Over Input

This alarm is only applicable when the DC Fail-Over is installed. This alarm input informs the controller that power is only available through the DC inverter, so the controller will only run the supply fan and outdoor air damper.

3.9.4 Electrical Connection to Controller Box



Important. The ethernet cable used must be wired according to ANSI/TIA-568-B.2 standard. Communication errors may occur if the cable is not wired correctly.

Follow these steps to complete the connections:

1. Open the controller box.
2. Connect the power cable to the controller breaker (QF1).
3. (Optional, ASMUC.6.AC Only) If using 240VAC to power the controller, follow instruction below to adjust the settings for AL1 and AL2 on the power protector (FV).
 - There are 2 voltage dials on the monitor, AL1 for overvolt and AL2 for undervolt. The label on the dial indicate percentage of 300V for alarm trigger. For example, 30% means the alarm will trigger at 90V. It is recommended to set the monitor to 15V above and below in coming power, although this can be adjusted depending on site
 - There are also 2 alarm LED on the left-hand side. If Indicator AL1 is lit, the voltage is above the overvolt limit. If alarm Indicator AL2 is lit, the voltage is below the undervolt limit.

- Reference chart

Incoming Voltage	Recommended Overvolt Limit	Recommended Undervolt Limit	Dial AL1	Dial AL2
110V	125V	95V	42%	32%
120V	135V	105V	45%	35%
208V	223V	193V	74%	64%
240V	255V	225V	85%	75%
253V	268V	238V	89%	79%




Figure 3-26 Phase Monitor

4. Ensure the PGD cable is FIRMLY plugged into the user interface terminal located on the inside of the controller box cover.




Figure 3-27 PGD Cable

5. Ensure that terminal J3 (behind J10) is securely plugged in to the control module.
6. Connect one ethernet cable per unit from a port on the network switch to the control module inside the unit (Behind J12).



Important. Do not run the Ethernet cables in the same conduit as prime power or other high voltage AC as this can result in communication errors.



3.9.5 Supplying Power to P-CRACs

Bring the power cable(s) to the P-CRAC through either the side panel or the back panel.

1. Connect the power cables to each P-CRAC (Refer to nameplate for electrical ratings)



Important. Do not run high voltage cable along same exterior conduit as low voltage/communication wire.



Important. Do not run cables through damper compartment to ensure wire/cables do not interfere with proper operation of the damper.




Figure 3-28 Prime Power Connections

2. Connect the Filter/Smoke alarm cable to the corresponding terminal.




Figure 3-29 Main Power Wiring and Filter/Smoke Alarm Wiring

3. Ground the system using ground lug or ground terminal.




Figure 3-30 Unit Grounding

3.10 Complete the Installation Checklist

The physical installation should be complete. Prior to starting the system, ensure that no steps have been omitted by completing this installation and wiring checklist.

Date: _____ **Unit Factory Number:** _____ (refer to the unit name plate)

Verify Physical Installation ✓ or ✗

Weather stripping has been attached to the air inlets and outlets of the WPUs between the wall and the unit.

All machines are securely fastened to the wall.

All leaks are sealed with silicone.

The indoor temperature sensor and humidity sensor have been installed and are mounted away from direct or indirect supply or return air stream. Sensors should also be mounted away from equipment or other heat sources.

The aluminum grills are fastened.

The brackets at the bottom of the compressor have been removed and the screws refastened.

The outdoor temperature sensor is inside the sensor box and mounted outside the shelter. Sensor box drain holes are facing downward and the through hole in the shelter wall has been sealed.

Verify Electrical Installation

Ethernet connections are secured.

The main voltage connections between each WPU and the prime power panel are secured.

The power connections between the controller box and power plant panel are secured.

Proper clearance is allowed between the cables and air damper in the WPU to avoid interference.

3.11 System Commissioning

A complete system operation verification is vital to ensure all components are operating correctly after installation. A system commissioning checklist is available on Page 49. Follow the instructions in this section to complete the checklist and leave a copy on site.

Note: See Table 4-1 on Page 49 for PGD button definitions.

3.11.1 Turn on Component Breakers and Primary Power

After completing the checklist, turn on all breakers in both the WPU's and controller box. Then reattach all covers and panels before turning on the breakers in the prime power panel.

3.11.2 Verify Proper Phase connection (3 Phase Power Only)

Verify "Normal" LED on the phase monitor (FV) is lit. Correct phase rotation if necessary.




Figure 3-31 P-CRAC Phase Monitor

3.11.3 Upgrade System Software

See Chapter 7: System Update for instructions. This is only required if the HVAC units or controller were obtained at different times or if a HVAC unit is being added to an existing install.

3.11.4 Change System Units (Optional)

By default, the system operates using units of °F and psi for temperature and pressure. These can be changed to metric units if desired.

1. Hold the Esc button until the main screen is displayed.
2. Press Up and Down together to enter the debug menu.
3. Press Down, the screen should display "No Conversion".
4. Press Enter until the cursor is on the row below "Current UoM"
5. Press Up or Down until the desired unit conversion is shown and press Enter.

3.11.5 Set IP Addresses for Controller (Optional for Remote Monitoring)

This step is needed if user intends to communicate to the device via IP. This step can be skipped and returned to later if user does not immediately intend to communicate to the system remotely.

1. Hold the Esc button until the main screen is displayed.
2. Hold Alarm and Enter for 3 seconds to enter the unit configuration menu.
3. Press Down until the cursor is over “Settings” and press Enter.
4. Press Down until the cursor is over “TCP/IPv4 Configuration” and press Enter.

```
Enable: Static
IP:    192.168.137.254
Mask:  255.255.0.0
GW:    0.0.0.0
DNS:   0.0.0.0

Update config? No
```

Figure 3-32 IP Configuration

5. Press Enter until the cursor is over the relevant fields of the IP address and Mask. Use the Up or Down buttons to change them to the desired values.
 - IP: Use the IP given by end user for remote monitoring
 - Mask: Always use 255.255.0.0
 - Gateway and DNS: Use values specified by end user or leave at 0.0.0.0
6. Press Enter until the cursor is over “Update Config” and press Up to change “No” to “Yes”.
7. Press Enter.

3.11.6 Remove the PGD from the Controller (If External Display Not Available)

To set the IP addresses for each unit, a PGD display must be connected to each unit. If an external PGD is not available, the one attached to the controller can be removed.

1. Open the controller box and disconnect the plug on the rear of the display.
2. Using a flathead screwdriver or similar tool, remove the PGD frame.



Figure 3-33 Remove PDG Frame

3. Remove the screws securing the PGD to the controller door.



Figure 3-34 Remove Screws of PGD

3.11.7 Set the Unit IP Addresses

The IP address of each unit needs to be set prior to integration into the control network.

1. Connect a PGD to the control module inside the unit using the preinstalled connector.
2. Hold the Esc button until the main screen is displayed.
3. Hold Alarm and Enter for 3 seconds to enter the unit configuration menu.
4. Press Down until the cursor is over “Settings” and press Enter.
5. Press Down until the cursor is over “TCP/IPv4 Configuration” and press Enter.
6. Press Enter until the cursor is over the relevant fields of the IP address and Mask. Use the Up or Down buttons to change them to the desired values.

IP Settings:

- If the previous section on changing IP for the controller was skipped, set the IP Address to 192.168.11.X where X is the unit number. For example, for Unit #3, set the IP Address to 192.168.11.3
- If the customer provides IP settings for each HVAC, change the values on the units accordingly.

- If you had changed the controller IP for remote monitoring, set IP to Y.Z.11.X where Y and Z are the same as the controller and X is the unit number. For example, if the controller IP is set to 192.168.20.45, set unit #1 to 192.168.11.1 and unit #2 to 192.168.11.2.
 - Mask: Always use 255.255.0.0
 - Leave other fields blank.
7. Press Enter until the cursor is over “Update Config” and press Up to change “No” to “Yes”.
 8. Press Enter.
 9. Repeat steps 1-8 for all units to be installed.

3.11.8 Verify the Unit Model Number

1. Hold the Esc button until the main screen is displayed.
2. From the Main Screen, press Prg and enter the password (0004).
3. Press Down until the cursor is over “HVAC Config” and press Enter. The cursor should be over “Unit Model”. Press Enter.
4. Verify that the displayed model number is consistent with the nameplate. Use the Up and Down buttons to change the model until it is correct. Press Enter to confirm.

3.11.9 Optional: Set the Unit Serial Number

1. Hold the Esc button until the main screen is displayed.
2. From the Main Screen, press Prg and enter the password (0004).
3. Press Down until the cursor is over “HVAC Config” and press Enter. The cursor should be over “Unit Model”. Press Enter.
4. Press Down until the cursor is over “Serial Number”, the press Enter.
5. Use the Up and Down buttons to change each digit of the serial number and press Enter to move to the next number.

3.11.10 Set the Number of Units and Zones

Note: If the PGD was removed from the controller to configure the unit IP addresses and the model and serial numbers, it must be reconnected before proceeding with the following steps.

1. On the main controller hold the Esc button until the main screen is displayed.
2. From the Main Screen, press Prg and enter the password (0004).
3. Press Down until the cursor is over “Control Config” and press Enter.
4. The cursor should be over “Network”. Press Enter.
5. Press Enter until the cursor is by “Total HVACs”. Use the Up and Down buttons to change the value until it matches the total number of HVACs connected to the controller. Press Enter to confirm.
6. Press Enter until the cursor is by “Total Zones”. Use the Up and Down buttons to change the number of temperature zones. Press Enter to confirm.

3.11.11 Zone Configuration (Optional)

The ASMUC.6 controller can control up to 6 units organized in up to 4 zones. A different temperature setpoint can be set for each zone. Each zone can have between 1 and 6 units and any unit can be assigned to any zone. To do so, perform the following steps from the controller: Hold the Esc button until the main screen is displayed.

1. Hold the Esc button until the main screen is displayed.
2. Press the Prg button and enter the password (0004).
3. Press Down until “Control Config” is selected and press Enter.
4. The cursor should be over “Network”. Press Enter.
5. Press Down until the screen below is displayed and press Enter.




Figure 3-35 Zone Configuration Screen

6. Press Enter until the cursor is next to the desired unit and in the “Zone” column.
7. Press Up or Down until the desired zone is selected and press Enter to confirm.
8. Press Enter until the cursor is in the right most column.
9. Press Up or Down to scroll through the unit setting. The settings should generally stay as “rotate”, even for single unit zones. If the unit is set to standalone, it will stay on unless turned off from the unit itself.
10. Repeat steps 6-9 for all units.
11. If more than four units need to be configured, press Enter until the cursor is blinking in the upper left corner and press Down to access additional units. Repeat steps 6-9 for all units that need to be configured.

3.11.12 Match Unit ID with IP Address

Note: This step can be skipped if the address of the unit was not changed from the default 192.168.11.X where X is the unit #.

The IP address of each unit must be matched to a unit ID. When this step is done, each unit will have a corresponding IP address.

1. Hold the Esc button until the main screen is displayed.
2. From the Main Screen, press Prg and enter the password (0004).
3. Press Down until the cursor is over “Control Config” and press Enter.

4. The cursor should be over “Network”. Press Enter.
5. Press Down until the cursor is next to “Network configuration”
6. Press Enter until the cursor is next to “Unit ID”.
7. Use the Up and Down buttons to select a Unit ID and press Enter to confirm.
8. Press Enter until the cursor is over the IP address.
9. Use the Up and Down buttons to change the value of each part of the IP address. When finished, press Enter to move to the next part of the IP address.
10. Once done, repeat steps 5-8 until each Unit ID in the control network has been assigned an IP address.

3.11.13 Turn the HVAC System On

1. Press Esc until the main screen is displayed.
2. Press Down until a power icon is displayed in the lower right corner of the display.
3. Press Enter.
4. Press Up until ON is displayed and then press Enter.




Figure 3-36 On/Off Screen



Warning. Never leave the site with the HVAC system in the off state. The site will have no cooling, which likely will result in a high temperature alarm requiring an urgent site visit to correct. When the HVAC system is on, the status in the bottom left corner of the main screen should read “ON”.

3.11.14 Execute the Step-Test

The step test systematically verifies that key components of the system are operating as expected. Note the following considerations:

- The steps in the test can be executed in any order; they do not need to be sequential.
- The Step Test takes the system out of automatic mode.

To perform the step test, follow these steps:

1. Hold Esc until the main screen is displayed.

2. From the Main Screen, press Prg and enter the password (0004).
3. Press Enter, the cursor should be over “Step Test”.
4. Press Enter to access the menu.
5. Press Enter, the cursor should be next to “Select HVAC ID”.
6. Press Up or Down until the unit to be tested is selected, then press Enter.
7. Press Down, then press Enter. The cursor should be next to STOP.
8. Use the Up and Down buttons to select the desired test and press Enter to confirm.
9. Repeat Step 8 for all 5 tests. Verify that all components are operating properly. The 5 tests are supply fan, heater, condenser fan, compressor, and damper.
10. After testing is complete, switch the test to STOP and press Enter.
11. When the step test is complete, return to the main menu by holding Esc.

Table 3-8 Step Test

Name	Action	Notes
Supply Fan	Turns on supply fan	
Heater	Turns on electric heater	Supply fan will run at full speed
Condenser Fan	Turns on condenser fan	
Compressor	Turns on compressor	Supply fan will run at full speed, condenser fan speed will adjust according to the pressure. Compressor will run at medium speed for 3 minutes before changing to the desired speed
Damper	Cycles damper between open and closed	

Optional: When running the supply fan, condenser fan, and compressor step tests, the speed of the component can be changed to test variable speed operation.

1. Repeat steps 1-8 in the above section until the desired step test is selected.
2. Press Down, the screen should display “Test settings”.
3. Press Enter until the desired component is selected.
4. Press Up or Down to adjust the speed and press Enter.

Note: Changing the speed of a component will change its speed only when testing that component. For example, changing the supply fan speed will not affect its run speed during the compressor step test.

Note: The unit will stay under manual control until step “STOP” is selected. Make sure that “STOP” is selected and the unit is on before leaving the site to avoid potential high temperature alarms. To verify, the system status on the main screen should be “ON”.



Warning. Once the compressor has been turned on, it must be allowed to run for at least three minutes before the next step to prevent compressor damage.

3.11.15 Set the System Clock

1. Press Esc until the main screen is displayed.
2. Press Prg and enter the password (0004). Press the Enter key.
3. Press Down until the "System" is selected, and press Enter. The cursor should be over "Date and Time". Press Enter.
4. Press Enter to access each individual date and time field.
5. Press Up or Down to change the value of each number and press Enter to verify and move on to the next value. Note: the system operates on 24hr time.
6. Press Enter when all fields have been verified. The cursor should be in the upper left corner.

3.11.16 Verify Sensor Readings

All the sensors are factory calibrated before shipping; however, it is essential to verify that all sensors connected to the controller box are properly installed.

1. Press Esc until the main screen is displayed.
2. Press Down until the "i" icon is showing in the bottom right of the display and press Enter.
3. Press Down until a "Controller Info" is displayed.
4. View the readings shown on the display and verify that they are correct.
5. Wrap a hand around the temperature sensors and verify that the readings change.
6. "Huff" into the humidity sensor with moist warm breath and verify that the humidity reading changes.

If the temperature sensor readings do not change when a hand is wrapped around the corresponding sensor, verify that they have been placed in the correct locations. If the humidity reading does not change, remove the cover and verify that the plug is seated correctly.

3.11.17 Verify Indoor Setpoint

1. Press Esc until the main menu is displayed.
2. Press Down until Set is displayed in the bottom right of the display and press Enter.
3. Press Enter until "Main Set" is selected.
4. Press Up or Down to change the setpoint and press Enter to confirm.
5. If multiple zones have been established, press Enter until the cursor is in the upper left corner and press Down to access the settings for each zone.
6. Repeat steps 3-5 until the settings for each zone have been entered.




Figure 3-37 Verify the Main Setpoint

3.11.18 Verify Input and Output Alarms

1. Verify Generator Signal

Note: If the alarm input logic is set incorrectly (NC/NO), no more than one unit will be permitted to run at any time.

- Place a jumper between wires 5 and 42 on the controller box terminal block.
- Press the Alarm button. The generator run alarm should be displayed in the alarm screen.
- Remove the jumper.

2. Verify Smoke/Fire Alarm Signal

- Press the test button on the smoke/fire detector. The system should completely shut down (Fans and compressors off, damper closed, the Smoke/fire alarm will be displayed on the alarm screen).
- The Smoke/Fire Alarm is connected to 41 and 5 on the controller terminal block. If the smoke/fire detector does not have a test button, remove one of the wires from terminals 41 and 5; the system should shut down. It may take the compressor 30 seconds to stop.

3. Verify HVAC Alarms

- HVAC1: Turn off the HVAC 1 prime power breaker at panel or unit. Verify NO terminal 44 and 45 is Closed.
- HVAC2: Turn off the HVAC 2 prime power breaker at panel or unit. Verify NO terminal 46 and 47 is Closed.
- HVAC3: Turn off the HVAC 3 prime power breaker at panel or unit. Verify NO terminal 47 and 48 is Closed.

3.11.19 Clearing Alarm History

At significant points such as during preventative maintenance and after commissioning, it may be desired to clear the alarm history.



Warning. Alarm history is collected because it can be very helpful in identifying a problem with the system. The alarm history should never be arbitrarily cleared by an operator. Only AAST should clear the alarm history after all the alarms stored in history have been recorded.

To clear the alarm history, perform the following steps:

1. Hold the Esc button until the main screen is displayed.
2. Press Prg and enter the password (0004). Press Enter.
3. Press Down until the cursor is over "System" and press Enter.
4. Press Down until the cursor is over "Initialization" and press Enter.
5. Press Down until the cursor is over "Delete Alarm Logs" and press Enter.
6. Press Up or Down until the "no" becomes "yes" and press Enter.

3.11.20 Enable SNMP (Optional)

SNMP is available on the ASMUC as an optional extra. To enable it, perform the following steps:

1. Hold the Esc button until the main screen is displayed.
2. Press Prg and enter the password (0004). Press Enter.
3. Press Down until the cursor is over "System" and press Enter.
4. Press Down until the cursor is over "Serial Ports" and press Enter.
5. Press Down until "SNMP Recipients Config" is displayed across the top.
6. Press Enter until the cursor is next to "SNMP" and use the Up or Down buttons to change "No" to "YES".
7. Press Enter to confirm.
8. Press Enter until the cursor is over the IP address fields.
9. Use the Up and Down buttons to change the value of each part of the IP address. When finished, press Enter to move to the next part of the IP address.
10. To add additional recipients, press Enter until the cursor is in the upper left corner and press Down to access the IP settings for the other recipients.
11. Repeat steps 7-10 as needed. Up to 5 recipients can be added.



Figure 3-38 Enable SNMP

3.11.21 Complete the Registration Card

The information on the registration card is critical for establishing the warranty start point.

The nameplates can be found on the outside of the P-CRAC and on the front of the controller box. These must be recorded on the AIRSYS Product Warranty Registration Card. The registration card can also be submitted online at <https://airsysnorthamerica.com/support/warranty-registration/>.

Commissioning Checklist	
Site name or building serial #: _____	Name of Tester: _____
ASMUC.6 Serial #: _____	Title/Position: _____
	Contact information: e. _____

Date Tested: _____	Ph. _____
1. Change System Units (Optional)	<input type="checkbox"/>
2. Set the Unit Model	<input type="checkbox"/>
3. Set the Unit Numbers	<input type="checkbox"/>
4. Turn ON the HVAC System	<input type="checkbox"/>
5. Execute Step Test (verifies all functions of each P-CRAC)	
• 5.1. HVAC Supply Fans	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>
• 5.2. HVAC Heaters	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>
• 5.3. HVAC Condenser Fans	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>
• 5.4. HVAC Mechanical Cooling	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>
• 5.5. HVAC Outside Air Damper	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>
6. Set the System Clock	<input type="checkbox"/>
7. Verify Temp and Humidity sensor readings and Setpoint	
• 7.1. Primary Indoor Temp sensor	<input type="checkbox"/>
• 7.2. Humidity sensor	<input type="checkbox"/>
• 7.3. External (outside) Temp sensor	<input type="checkbox"/>
• 7.4. Confirm indoor temperature setpoint	<input type="checkbox"/>
8. Verify Signal from Generator	<input type="checkbox"/>
9. Verify Smoke/Fire Alarm	<input type="checkbox"/>
10. Verify HVAC Alarms	<input type="checkbox"/>
11. Verify DC-Failover (if installed)	<input type="checkbox"/>
12. Clear Alarm History (Optional)	<input type="checkbox"/>
13. Fill out Warranty Card and send to AIRSYS Cooling Technologies	<input type="checkbox"/>

PRODUCT INFORMATION

Controller	Model #: _____	Serial #: _____
WPU #1	Model #: _____	Serial #: _____
WPU #2	Model #: _____	Serial #: _____
WPU #3	Model #: _____	Serial #: _____
WPU #4	Model #: _____	Serial #: _____
WPU #5	Model #: _____	Serial #: _____
WPU #6	Model #: _____	Serial #: _____

INSTALLATION INFORMATION

Site #: _____ Site Name: _____

Street address: _____ City: _____ State: _____ Zip: _____

Date Install Completed: ____/____/____ Installation Company: _____

Installer Name: _____ Phone #: _____ Email: _____

OWNERSHIP INFORMATION

Company: _____

Site Supervisor Name: _____ Phone #: _____ Email: _____

REGISTRATION ONLINE: airsysnorthamerica.com/support/warranty-registration

BY EMAIL: Scan and send to: support@air-sys.us

4. System Operation

This chapter describes how to use the PGD interface (Figure 4-1) to execute the functions needed during standard operation. This information may be useful during troubleshooting and in conversations with technical support. For a list of changeable parameters, see Page 5.

The following topics are covered:

- Using the Main Menu to execute basic functions
- Understanding alarms that may occur and clearing alarm history
- Additional system diagnostic information






Figure 4-1 PGD User Interface




4.1 User Interface Introduction

The units are controlled using the PGD interface, which has 6 buttons (Table 4-1). A PGD is preinstalled in the ASMUC controller which can be used to control all connected WPU's. In addition, a separate PGD can be connected to a preinstalled display cable on the unit for detailed diagnostics. The preinstalled cable leads from the J3 connector on the controller module and terminates in the display connector. All settings from the controller will override settings inputted at the unit unless the unit has been set for standalone operation.

For this section, “controller” will refer to the ASMUC.6 controller box and “system” will refer to the controller AND all connected units.

Table 4-1 PGD Button Actions

Button	Function	Description
	Alarm	Displays current alarms. Indicates active alarm when the LED is on.
	Program	Enter the menu selection page.
	Esc	Go up one level in any menu.

Button	Function	Description
	Up	Scroll up through menu screens and options Increase the value of selected parameter
	Enter	Select a parameter to be changed. Confirm a changed parameter.
	Down	Scrolls down through menu screens and options Decrease the value of selected parameter.

4.2 Navigating Menus

The user interface is broken down into main menus and program menus. Main menus are accessed through the main screen, while program menus are accessed through the program menu selection screen. Please note the following when navigating the menus:

The current position in the menu is marked by a blinking cursor.

- When the cursor is in the top left corner of the screen, press Up or Down to navigate to different menu screens.
- To enter a menu screen, press Enter.
- When inside the menu screen, press Enter to scroll through the different parameters.
- After the desired parameter is selected, press Up or Down until the desired setting is selected and press Enter to confirm.
- To exit a menu screen, press Enter until the cursor is in the top left corner. The Up and Down buttons can then be used to navigate to different menu screens.

4.3 Main Screen

The Main Screen is displayed by default upon system startup. It can also be accessed from any point by holding the Esc button.



Figure 4-2 Main Screen

The system status is shown in the bottom left corner. There are 5 possible statuses, which are shown in Table 4-2

Table 4-2 System Statuses

System Status	Status Description	Notes
On	Unit is on	
Off By Alarm	Unit operation is stopped due to alarms	
Off By BMS	Unit has been turned off by the BMS	Displayed on HVAC when the master controller is "Off by Keyboard"
Off By Keyboard	Unit has been turned off locally	
In Manual Mode	Unit is operating in manual mode (step test)	Can be engaged at the unit or controller

The four main menus can be accessed from the main screen. The menus are selected by pressing the Up or Down buttons. The icon in the bottom right corner will change accordingly. Press Enter to access the menu.

- When the power icon is displayed, press Enter to access the power menu. The system can be switched on and off from here.
- When the i icon is displayed, press Enter to access the information menu. This menu contains information regarding the system status, sensor readings, equipment runtime, and system data. If viewing from the controller, information for each connected unit can be viewed from this menu.
- When Set is displayed, press Enter to access the setpoint menu. The main temperature and comfort mode setpoints for each zone can be assigned. In addition, the free cooling humidity limit can also be set.
- When Cft is displayed, press Enter to access the comfort mode menu. The system can be toggled between normal and comfort mode.

4.3.1 Turning the System On and Off

1. Hold the Esc button until the main screen is displayed.
2. Press Up or Down until the power icon is displayed in the bottom right of the screen and press Enter.
3. Press Up or Down to switch between On and Off, press Enter to confirm.




Figure 4-3 On/Off Screen



Warning. Never leave the site with the HVAC system in the off state. The site will have no temperature control, which likely will result in an urgent site visit to correct.

4.3.2 Changing the Setpoint and Free Cooling Humidity Limit

The setpoint for each zone can be independently adjusted from the controller. In addition, the free cooling humidity limit can be adjusted, but will apply for the whole network.

1. Hold the Esc button until the main screen is displayed.
2. Press Up or Down until the Set is displayed in the bottom right of the screen and press Enter.
3. Press Down until the desired zone is selected. The screen should display “ZoneX Room Temperature”. Press Enter.
4. Press Enter until the cursor is next to “Main Set”.
5. Press Up or Down to change the setpoint and press Enter to confirm.
6. If setpoints for more than one zone need to be configured, press Enter until the cursor is in the upper left corner and repeat steps 3-5.




Figure 4-4 Setpoint Screen

To change the free cooling humidity limit, repeat steps 1-3, but scroll to the screen that reads “Outdoor Humidity” Then press Enter and use the Up and Down keys to adjust the humidity limit. Press Enter to confirm.

4.3.3 Using Comfort Mode

The settings on the HVAC system are optimized for operating efficiency and not for human comfort. When working inside the shelter for extended durations, the site temperature can be temporarily adjusted using the comfort mode setting.

1. Hold the Esc button until the main screen is displayed.
2. Press Up or Down until the CFT is displayed in the bottom right of the screen and press Enter.
3. Press Up or Down to switch between Comfort and normal mode, press Enter to confirm.

To change the comfort mode setpoint, see “Changing the Setpoint and Free Cooling Humidity Limit”.



Important. If the HVAC system needs to cool aggressively to reach the comfort mode setpoint, multiple WPU's may go into mechanical cooling.



Figure 4-5 Comfort Mode Screen

4.3.4 Changing System Units

By default, the system operates using units of °F and psi for temperature and pressure. These can be changed to metric units if desired.

1. Hold the Esc button until the main screen is displayed.
2. Press Up and Down together to enter the debug menu.
3. Press Down, the screen should display “No Conversion”.
4. Press Enter until the cursor is on the row below “Current UoM”
5. Press Up or Down until the desired unit conversion is shown and press Enter.




Figure 4-6 Unit Selection Screen

4.3.5 Viewing Controller Information

System information such as unit status and energy consumption as well as controller status can be viewed from the controller. See Table 4-3 for a complete list of information viewable from the controller. All parameters are read-only.

1. Hold the Esc button until the main screen is displayed.
2. Press Up or Down until i is displayed in the bottom right of the screen and press Enter.

- Use the Up or Down buttons to scroll through the menu screens.

Table 4-3 Controller Info Menu

Menu Screen	Parameter	Description
Network Status	Network Status	View unit status
HVAC Info	ID Fan	Supply fan speed
	Comp	Compressor speed
	OD Fan	Condenser fan speed
	Damper	Damper position
	Heater	Heater Status
	kW	Energy consumption
	Status	Unit status
Avg KW	1 Hour	Average energy consumption in the past hour for all units
	30 Days	Average energy consumption in the last 30 days for all units
Sensor Reading	Outdoor temp	Outdoor temperature reading from controller
	Room temp 1	Room temperature reading from controller
	Humidity	Humidity reading from controller
	Room temp 2	Zone 2 room temperature
	Room temp 3	Zone 3 room temperature
	Room temp 4	Zone 4 room temperature
Alarm Inputs	Smoke/fire	Smoke/fire alarm status
	Generator run	Generator run alarm status
	DC failover	DC failover run status
	Hydrogen	Hydrogen alarm status
Alarm Outputs	High temp	High temp alarm status
	HVAC Alarm 1	HVAC 1 alarm status
	HVAC Alarm 2	HVAC 2 alarm status
	HVAC Alarm 3	HVAC 3 alarm status
Drive Signal	Residual Press. Valve	Residual Pressure Valve Status
	Select Unit ID	Select the unit to view
HVAC ID Select	Goto HVAC Info	Change "NO" to "YES" and press Enter to view unit status.
	SW ver.	Software version
Controller info	OS ver.	Operating system version
	BOOT ver.	Bootloader version
PRESS [ENTER] TO VIEW ADVANCED INFO		
System info	Board type	Control board model
	Board size	Control board size
	Board temp	Control board temperature

Menu Screen	Parameter	Description
	Ret mem writes	Memory writes
Run Time	Controller	Controller operating hours
	Current time	Current time
Power Off Info	Power off time	Last time the unit was powered off
	Length last time off	Length of last unit shutdown

4.3.6 Viewing Unit Information

Information such as suction and discharge temperatures, system pressures, compressor speed, and energy consumption can be viewed for all units from the controller. Table 4-4 contains unit information that can be viewed either at the controller or directly at the unit. All parameters are read-only.

4. Hold the Esc button until the main screen is displayed.
5. Press Up or Down until i is displayed in the bottom right of the screen and press Enter.
6. Press Down until "Select HVAC ID" is displayed on the screen and press Enter.
7. Use the Up or Down buttons to select the unit to be viewed and press Enter.
8. Press Down until the cursor is over "Goto HVAC Info" and press Enter.




Figure 4-7 HVAC ID Select Screen

9. Press Down until "NO" becomes "YES" and press Enter.
10. Press Down until a menu titled "Info" is displayed.
11. Press Up or Down to scroll through the unit information.

Table 4-4 Unit Info Menu

Menu Screen	Parameter	Description
	Unit request.	Compressor speed requested by the unit
Capacity Regulation	Required cap.	Compressor speed requested by the controller
	Actual cap.	Current compressor speed (%)
	Actual speed	Current compressor speed (rps)
Inverter Info	DC Voltage	DC voltage to inverter

Menu Screen	Parameter	Description
	Current	Current to inverter
	Amb Temp.	Ambient temperature
	Driver temperature	Inverter driver temperature
Refrig. Pressure	Suct. Pressure	Suction pressure
	Disc. Pressure	Discharge pressure
	Press. Diff.	Pressure difference between compressor suction and discharge
	Press. Ratio	Pressure ratio between compressor suction and discharge
Refrig. Temperature	Disc. Temp	Discharge temperature
	Cond. Temp	Condensing temperature
	Cond. Sat. Temp	Condensation saturation pressure
	Suct. Temp	Suction temperature
	Suct. Sat. Temp	Suction saturation temperature
EEV Info	EEV Step	EEV Step
	EEV Status	EEV opening percentage
	Super Cool	Unit Subcooling
	Super Heat	Unit Superheat
Sensor Reading	Supply temp.	Unit supply temperature reading
	Return temp.	Unit return temp reading
	Outdoor temp.	Unit outdoor temperature reading
	Humidity	Unit humidity reading
	Backup temp.	Unit backup temperature sensor reading
Alarm inputs	Smoke/fire	Smoke/fire alarm input status
	Comp. ovl	Compressor overload alarm input status
	HP switch	High pressure alarm input status
	Power failure	Power failure alarm input status
	Filter clogged	Dirty filter alarm input status
	Supply fan ovl.	Supply fan overload alarm input status
	AFPD	AFPD trigger alarm input status
Component Status	Compressor	Compressor status

Menu Screen	Parameter	Description
	Supply fan	Supply fan status
	Heater	Heater status
	EEV	EEV status
	Supply fan	Supply fan speed
	Speed	Supply fan rotation speed (rpm)
	FC damper	Damper opening percentage
Drive Signal	Supply Fan	Supply fan speed
	FC damper	FC damper opening
	Cond. fan	Condenser fan speed
	Cond. Fan. Dirty Rate	Condenser Fan Dirty Rate
Run Time	Unit	Unit operating hours
	Supply fan	Supply fan operating hours
	Compressor	Compressor operation hours
	Heater	Heater operating hours
	Free Cooling	Free cooling operating hours
Start times	Supply fan	Number of supply fan starts
	Compressor	Number of compressor starts
	Heater	Number of heater starts
	Free cooling	Number of free cooling starts
Power Off Info	Current time	Current time
	Power off time	Last time the unit was powered off
	Length last time off	Length of last unit shutdown
HVAC Model	HVAC Model	HVAC Model Number

4.4 Program Menus

Program Menus can be accessed through the program menu selection screen. Changing most system settings require accessing a program menu. From the main screen, press Prg to access the program menu selection screen. Accessing a program menu requires a password. There are three password protected access levels: user, service, and manufacturer. Enter the password, using the Enter button to move the cursor horizontally and the Up and Down buttons to change the numbers. Once the password is entered, hold Enter until the selection screen is displayed.

The user level gives limited access to system parameters, the service level allows access to critical component settings such as the EEV and compressor, and the manufacturer level allows for modification of all system parameters. The default passwords for the user and service levels are 0003 and 0004. Contact AIRSYS Support for access to manufacturer parameters.

The current access level is shown in the upper left corner of the program menu selection screen. To change access levels, scroll through the program menu selection screen until "Logout" is highlighted and press Enter until the main screen is displayed. Then press Prg and log in with the appropriate password.




Figure 4-8 Program Menu Selection Screen

4.5 Step Test

The step test systematically verifies that key components of the system are operating as expected. Note the following considerations:

- The steps in the test can be executed in any order; they do not need to be sequential.
- The Step Test takes the system out of automatic mode.

To perform the step test, follow these steps:

1. Hold Esc until the main screen is displayed.
2. From the Main Screen, press Prg and enter the password (0004).
3. Press Enter, the cursor should be over "Step Test".
4. Press Enter to access the menu.
5. Press Enter, the cursor should be next to "Select HVAC ID".
6. Press Up or Down until the unit to be tested is selected, then press Enter.
7. Press Down, then press Enter. The cursor should be next to STOP.
8. Use the Up and Down buttons to select the desired test and press Enter to confirm.
9. Repeat Step 8 for all 5 tests. Verify that all components are operating properly. The 5 tests are supply fan, heater, condenser fan, compressor, and damper.
10. After testing is complete, switch the test to STOP and press Enter.
11. When the step test is complete, return to the main menu by holding Esc.




Figure 4-9 Step Test Selection Screen

Table 4-5 Step Test

Name	Action	Notes
Supply Fan	Turns on supply fan	
Heater	Turns on electric heater	Supply fan will run at full speed
Condenser Fan	Turns on condenser fan	
Compressor	Turns on compressor	Supply fan will run at full speed, condenser fan speed will adjust according to the pressure. Compressor will run at medium speed for 3 minutes before changing to the desired speed
Damper	Cycles damper between open and closed	

When running the supply fan, condenser fan, and compressor step tests, the speed of the component can be changed to test variable speed operation.

1. Repeat steps 1-8 in the above section until the desired step test is selected.
2. Press Down, the screen should display “Test settings”.
3. Press Enter until the desired component is selected.
4. Press Up or Down to adjust the speed and press Enter.

Note: Changing the speed of a component will change its speed only when testing that component. For example, changing the supply fan speed will not affect its run speed during the compressor step test.

Note: The unit will stay under manual control until step “STOP” is selected. Make sure that “STOP” is selected and the unit is on before leaving the site to avoid potential high temperature alarms. To verify, the system status on the main screen should be “ON”.



Warning. Once the compressor has been turned on, it must be allowed to run for at least three minutes before the next step to prevent compressor damage.

4.6 Alarms

When a problem occurs during unit operation, the controller records the related information and the Alarm button will be lit. Depending on the severity of the alarm, various components are automatically shut down. The system will automatically restart most components after a defined delay period. However, manual reset is required when certain alarms occur three times within an hour (configurable). A description of all system alarms is given below.

Table 4-6 Alarm Descriptions

Code	Description	User/Auto Reset
AL*01	Too Many Internal Memory Writes	User reset
AL*02	Internal Memory Read/Write Error	User reset
AL*03	Outdoor Temperature Sensor Error	Auto reset
AL*04	Indoor Temperature Sensor Error	Auto reset
AL*05	Humidity Sensor Error	Auto reset
AL*06	Smoke/Fire alarm	Auto reset
AL*07	Generator Run	Auto reset
AL*08	DC Failover Active	Auto reset
AL*09	AC Power Failure	Auto reset
AL*10	Low Press Lockout	User reset
AL*11	High Temp Alarm	Auto reset
AL*12	Low Temp Alarm	Auto reset
AL*13	Hydrogen Alarm	Auto reset
AL*14	Dirty Condenser Alarm	User reset
AL*47	High Pressure Sensor Error	Auto reset
AL*48	Discharge Temperature Sensor Error	Auto reset
AL*49	Suction Pressure Sensor Error	Auto reset
AL*50	Suction Temperature Sensor Error	Auto reset
AL*51	Supply Temperature Probe Error	Auto reset
AL*52	Condenser Temperature Probe Error	Auto reset
AL*53	Compressor Overload	Auto reset

Code	Description	User/Auto Reset
AL*54	High Pressure Switch Alarm	Auto reset
AL*55	Supply Fan Overload	Auto reset
AL*56	High Pressure Alarm	Auto reset
AL*57	Low Pressure Alarm	Auto reset
AL*58	Low Pressure Limit Alarm	Auto reset
AL*59	Stuck Filter Alarm	Auto reset
AL*60	AFPD Protection Triggered	Auto reset
AL*61	High Supply Temperature Alarm	Auto reset
AL*62	Damper Alarm	Auto reset
AL*63	Low supply Temperature Alarm	Auto reset
AL*64	Expansion Board Offline	Auto reset
AL*65	Master Controller Offline	Auto reset
AL*68	Low delta pressure	Auto reset
AL*69	High Discharge Temperature Alarm	Auto reset
AL*142	Inverter Offline	Auto reset
AL*143	Low Superheat Alarm	Auto reset
AL*144	Low Evaporator Temperature Alarm	Auto reset
AL*145	High Evaporator Temperature Alarm	Auto reset
AL*146	Low Suction Pressure	Auto reset
AL*147	EEV Alarm	Auto reset
AL*148	Emergency Ventilation Active	Auto reset
AL*149	Out of Envelope	Auto reset
AL*159	Air Filter Pressure Differential Alarm	Auto reset

If the Alarm button is illuminated, press it at the main screen to display current active alarms. The code identifying the system alarm will display on the screen of the user terminal. Press Up or Down to scroll through all active alarms. Press Esc to return to the main screen.

4.6.1 Alarm History

The controller stores up to 200 alarms which are individually timestamped and can be viewed in the Alarm History.

To access the alarm history, perform the following steps:

1. Hold the Esc button until the main screen is displayed.
2. Press Prg and enter the password (0004). Press Enter.
3. Press Down until the cursor is over “Alarm Logs” and press Enter.
4. Press Up or Down to scroll through the alarm logs.




Figure 4-10 Alarm Logs

4.6.2 Clearing Alarm History

At significant points such as during preventative maintenance, it may be desired to clear the alarm history.



Warning. Alarm history is collected because it can be very helpful in identifying a problem with the system. The alarm history should never be arbitrarily cleared by an operator. Only AAST should clear the alarm history after all the alarms stored in history have been recorded.

To clear the alarm history, perform the following steps:

1. Hold the Esc button until the main screen is displayed.
2. Press Prg and enter the password (0004). Press Enter.
3. Press Down until the cursor is over “System” and press Enter.
4. Press Down until the cursor is over “Initialization” and press Enter.
5. Press Enter until the cursor is over “Delete Alarm Logs”.
6. Press Up or Down until the “no” becomes “yes” and press Enter.




Figure 4-11 Clear Alarm History

4.7 Exporting System History and Alarm Logs

The system logs and alarm history can be downloaded to a personal computer through a USB connection from the controller to the computer. A micro USB to USB cable is required.

4.7.1 Exporting System Logs

1. Hold the Alarm and Enter buttons until the hardware configuration menu is displayed.




Figure 4-12 Hardware Configuration Menu

2. Press Down until the arrow is next to “Diagnostics” and press Enter.
3. The screen should display “System Log”. Press Enter.
4. Press Enter and wait until “Saving successful” is displayed. Press Esc until the hardware configuration menu is displayed.
5. Press Up or Down until the arrow is next to “Logger” and press Enter.
6. The arrow should be next to “Export Logs”. Press Enter.
7. Press Down until the arrow is next to “NewLog” and press Enter.
8. Wait until “Log operation ok” is displayed and press Enter.
9. Connect the controller and a computer using a microUSB to USB cable. The folder containing the logs should appear as a new drive. The logs can then be copied to the computer and viewed.

4.7.2 Exporting Alarm History

1. Hold the Esc button until the main screen is displayed.
2. Press Prg and enter the password (0004). Press Enter.
3. Press Down until the cursor is over “Import/Export” and press Enter.
4. Press Down until the cursor is over “Alarm Export” and press Enter.
5. Press Enter until the cursor is over “File name” and press the Up or Down buttons to change the log number. Press Enter to confirm.
6. Press Down until the “no” becomes “yes” and press Enter.
7. Connect the controller and a computer using a micro USB to USB cable. The folder containing the logs should appear as a new drive. The logs can then be copied to the computer and viewed.

4.8 Resetting Factory Defaults

In some cases, it may be necessary to restore the controller to factory defaults. Depending on the option selected, custom setpoints and other system parameters will be changed to factory defaults.

Note: Resetting factory defaults should only be done under the instruction of AIRSYS support.

There are three types of available factory resets:

- Restore factory settings (Wipe retain mem)
- Reset system memory (Wipe NVRAM mem)
- Full factory reset (Wipe both mem)

Restoring factory settings will restore all settings to factory defaults but will not affect stored data such as alarm and system logs. Resetting the system memory will clear all stored data but will not change any system settings. The full factory reset will restore all settings to factory default and wipe the system memory.



Important. System must be commissioned if you reset it to factory default. Follow the commissioning steps on Page 46 to re-commission the system

To perform a factory reset perform the following steps:

1. Hold the Esc button until the main screen is displayed.
2. Press Prg and enter the password (0004). Press Enter.
3. Press Down until the cursor is over “System” and press Enter.
4. Press Down until the cursor is over “Initialization” and press Enter.
5. Press Down until “Default Installation” is displayed across the top of the screen.
6. Press Enter until the desired option is selected.
7. Press Up or Down until “NO” becomes “Yes” and press Enter.
8. Wait for the system to automatically reboot and follow the on-screen instructions if given.



Figure 4-13 Factory Reset Screen

If performing a factory reset on a unit, cycle the unit breaker after the reset is complete. This is necessary for the unit to receive system setpoints from the controller.

4.8.1 Set the Master

If performing a factory reset on the controller, it must be set to “Master” after the reset is complete. Do so through the following steps:

1. Press the Up and Down buttons at the same time to enter the Debug Menu.
2. Press Down to scroll to Master/HVAC Select and press Enter.
3. Press Down until “Master” is selected and press Enter to confirm.




Figure 4-14 Set the Master

4.9 Operational Logic

4.9.1 Free Cooling (Economizer) Operation

When Free Cooling (FC) is engaged, the damper opens to introduce cooler air from outside to be delivered to the shelter. The damper will open when the difference between the indoor and outdoor temperatures is larger than a predefined minimum (default 3.6°F, configurable under “Free Cooling” in the User Configuration menu) and the outdoor humidity is below the limit (default 85%).

The supply fan will start at low speed when the damper opening conditions are met and the indoor temperature is above the Free Cooling Setpoint (configurable under “Room Temperature” in the User Configuration menu). As the indoor temperature rises, the fan speed will increase to keep the indoor temperature within 2°F of the main setpoint. If the indoor temperature cannot be maintained below the lead compressor turn on point (configurable under “Room Temperature” in the User Configuration menu), the compressor will start to assist FC.

During cold weather, the outdoor damper modulates to keep the supply air temperature above 51.8°F and will close completely when the supply temperature is below that point (configurable under “Supply Temperature” in the User Configuration menu). The damper will also close if the humidity is above the limit (default 85%) or if the AFPD dust sensor triggers a protection event.

If partial free cooling is allowed (default enabled), the damper can remain open when the compressor is engaged, provided that the outdoor temperature is lower than the indoor temperature. Otherwise, the damper will close as soon as the compressor starts. For shelters without a secondary pressure relief (e.g. a barometric louver), partial free cooling can be disabled (configurable under “Free Cooling” in the User Configuration menu).

4.9.2 Mechanical Cooling Operation

All AIRSYS Precision Cooling P-CRACs have variable speed compressors which will adjust their speed to match the heat load inside the shelter. The compressor logic will vary based on whether free cooling is engaged. If free cooling is enabled, the compressor will not start until the indoor temperature has reached a predetermined level above the setpoint (default 2°F). At that point, the compressor will start at full speed and adjust its speed according to the indoor temperature. These settings can be configured under “Setpoints” in the Control Configuration menu.

4.9.3 Heater Operation

The heater will activate when the indoor temperature reaches a predetermined level below the setpoint (default 29°F). The heater will then run until the temperature is a certain level above the on point (default 3°F). These settings can be configured under “Setpoints” in the Control Configuration menu.




Figure 4-15 Heater Operation Logic

4.9.4 Dehumidification

Dehumidification using the compressor or heater is available using the compressor or heater. It can be enabled under “Setpoints” in the Control Configuration menu. When the humidity reading from the controller exceeds a threshold (default 15% above target), dehumidification will activate. The heater will activate if the indoor temperature is below a certain level (default 11°F below setpoint). Otherwise, the compressor will be used to dehumidify. Dehumidification will stay active until the target is reached (default 55%).




Figure 4-16 Dehumidification Logic

4.9.5 Generator Run

If a generator run circuit is installed, the system can be set to limit free cooling and compressor speed when the generator is running. When the alarm signal is received, compressor speed will be limited to a default of 80%. This can be changed under “Alarms” in the HVAC Configuration Menu. Free cooling is not limited by default but can be disabled during generator operation to stop diesel fumes from entering the site.

4.9.6 Emergency Ventilation

When the indoor temperature is a much higher than the setpoint (default 14°F), emergency ventilation will start. The compressor will operate at full speed and the damper will open unless it is completely disabled. Emergency ventilation will continue to operate until the temperature is below a cutoff point (default 9°F below activation) at which point the system will return to normal operation.

4.9.7 Seaside Mode

Seaside mode will disable free cooling unless the conditions for emergency ventilation are met.

4.9.8 AFPD

The Air Filter Protection Device (AFPD) will automatically shut the damper when it detects a particulate concentration that is higher than a preset concentration (adjustable between 0.15-0.35 mg/m³). When a protection event is triggered, the damper will automatically shut. It will remain shut for a minimum of 1 hour and display the AL*60 alarm unless the controller is manually reset.

After the hour, it will sample the particulate concentration at one minute (configurable) intervals and reopen the damper when it is below the opening threshold.

4.9.9 Condenser Monitoring

The heat transfer across the condenser coil is monitored by the system and can be used to schedule preventative maintenance when the efficiency is low. Condenser status can be monitored under “Cond. fan dirty rate” in the Unit Info Menu” shown on Page 58.

5. System Parameters and Default Values

This section provides a listing of all changeable parameters in the PGD user interface. Authorized technicians may use the information in this section to change factory settings. The main menu and associated menu screens are covered in “Main Screen” on Page 60.

5.1 Step Test Menu Parameters

The Step Test menu is used to access the step test. See “Step Test” on Page 68 for additional information and instructions for executing the step test.

5.2 HVAC Config Menu Parameters

The HVAC Config menu contains configuration options for the following components, each of which has its own menu:

- Supply (Evaporator) Fan
- Condenser Fan
- EEV
- Compressor
- Inverter
- Alarms

Table 5-1 Parameters in the Supply Fan Menu

Menu Screen	Option	Description	Default
Supply Fan	Min Speed	Minimum allowed fan speed	30%
	Max Speed	Maximum allowed fan speed	100%
	Prime Power Fail	Maximum fan speed when the unit has no AC Power	80%
Supply Fan PID	Kp	Proportional control setting	4.0
	Ki	Integral control setting	30
	Kd	Derivative control setting	0
DX Fan Speed	Fixed DX Max Speed	Supply fan speed when the compressor is on and system is in fixed speed mode	100%
	Variable DX Max Speed	Supply fan speed when the compressor is on and system is in normal speed (variable) mode	93%
	Dehumidification Speed	Supply fan speed during dehumidification	75%

Table 5-2 Parameters in the Supply Fan Menu

Menu Screen	Option	Description	Default
Condensing Fan Speed	Min Speed	Minimum allowed fan speed	30%
	Max Speed	Maximum allowed fan speed	100%
Condensing Fan Setting	Setpoint	Condensation pressure setpoint	391.6 psi
	Deadband	Condensation pressure control deadband	7.3 psi
	Cut off difference	Condenser fan shut off pressure difference	43.5 psi
	HP Protect	High pressure protection	Enabled
	Off Delay Time	Condenser fan delay when turning off	20s
Condensing Fan PID	Kp	Proportional control setting	5.0
	Ki	Integral control setting	5
	Kd	Derivative control setting	0
Snow Setting	Wipe Snow	Snow removal functionality	Disabled
	Setpoint	Snow removal temperature setpoint	32°F
	Diff	Temp differential for snow removal	0°F
	Fan on time	Condensing fan on time during snow removal	0 min
	Fan off time	Condensing fan off time during snow removal	0 min

Table 5-3 Parameters in the EEV Menu

Menu Screen	Option	Description	Default
EEV	Enable exp. Board	Enable EEV driver	Enabled
	Address	Driver address	3
	New address	New Driver Address	3
	Cmd. Delay	Driver instruction delay time	30ms
	Timeout	Driver instruction timeout	2000ms
	Enable EEV	Enable EEV	Yes

Table 5-4 EU EEV Configuration Options

Note: This menu is only available when the display is directly connected to the unit.

Menu Screen	Option	Description	Default
Enable Device	Main Refrigerant	Unit refrigerant	R410A
	Enable LOP	Enable LOP control. 0/1 represents Disabled/Enabled	1
	Control Type	EEV control type	Auto
	Start position	EEV start position	50%
	Start Keep T	Start position holding time	60s
	Total Step	Total number of steps	250
	Max Open	Maximum opening percentage	100%
	Manual Open	Manual opening percentage	50%

Menu Screen	Option	Description	Default
	MOP Enable	Enable MOP control. 0/1 represents Disabled/Enabled	1
	MOP Set	MOP Setpoint	13.6K
	EEV Kp	Proportional control setting	4
	EEV Ki	Integral control setting	25s
	EEV Kd	Derivative control setting	0s
	SH Set	EEV superheat setting	10.0K

Table 5-5 Carel EEV Configuration Options

Note: This menu is only available when the display is directly connected to the unit.

Menu Screen	Option	Description	Default
Enable Device	Setup Done	EVD driver setup status. Will display YES when setup is complete.	No
	Default Request	Driver initialization	No
Superparameters	Valve	EEV model	Carel E2Vu
	Main regulation	Compressor type	BLDC
	Auxiliary Regulation	Compressor type	BLDC
System Configuration	Main Refrigerant	Refrigerant type	R410A
	Auxiliary Refrigerant	Refrigerant type	Same as main reg
Regulation	Superheat setpoint	Superheat setpoint	18°F
	Valve open at start up	EEV opening percentage during pre-opening	50%
	Pre-positioning time	EEV pre-opening time	6s
	Stand-by Valve Opened	EEV standby status	Disabled
	Valve position	EEV valve opening percentage during standby	0%
	Prop. gain	Proportional control setting	15
	Integ. Time	Integral control setting	150s
	Deriv. Time	Derivative control setting	15s
Low SH Protection	Threshold	Low superheat threshold	3.6°F
	Integral time	Integral control setting	10s
	Alarm delay	Alarm delay time	300s
LOP Protection	Threshold	Low evaporation temperature threshold	-58°F
	Integral time	Integral control setting	10s

Menu Screen	Option	Description	Default
	Alarm delay	Alarm delay time	300s
	Threshold	High evaporation temperature threshold	78°F
MOP Protection	Integral time	Integral control setting	20s
	Alarm delay	Alarm delay time	600s
Manual Positioning	Enable	Enable/Disable manual positioning	Disabled
	Position	Manual valve position	0 Step
Advanced	Power supply mode	Power supply	24 VAC
Alarms configuration	Alarm thresh.	Low suction temperature alarm threshold	-58°F
	Alarm timeout	Alarm timeout	300s

Table 5-6 Parameters in the Compressor Menu

Menu Screen	Option	Description	Default
Compressor Safety Time	Min. Run Time	Minimum compressor operating time	180s
	Min. Stop Time	Minimum compressor off time	180s
	Min. time btw. start	Minimum time between two compressor starts	360s
Compressor PID	Kp	Proportional control setting	90.0
	Ki	Integral control setting	60
	Kd	Derivative control setting	0
Comp speed Setting	Fixed speed	Compressor speed when unit is in fixed speed mode	42.0 rps
	Dehum. speed	Compressor speed during dehumidification	100%
	Gen Run speed	Max compressor speed when generator is running	80%
Comp. oil recovery	Enable	Enable compressor oil recovery	Enable
	Min. request	Minimum requested speed during oil recovery	55.0%
	Min. speed	Minimum compressor speed during oil recovery	30.0 rps
	Delay time	Delay time	60s
	Force speed	Oil recovery compressor speed	54.0 rps
	Force time	Oil recovery time	3s
Discharge Gas Mgmt.	Limit Temp	Discharge gas temperature limit	194°F
	Protect Temp	Discharge gas protection temperature	203°F
	Alarm Temp	Discharge temperature alarm setpoint	248°F
	Diff	Discharge temperature control difference	9°F
	Cycle Time	Discharge temperature control time	210s

Table 5-7 Parameters in the Inverter Menu

Menu Screen	Option	Description	Default
Comp. & INV	Enable Comp. INV	Enable compressor inverter	Enable
	INV Factory	Inverter driver manufacturer	EU
	Device address	Driver address	1
	New address	New driver address	0
	Cmd. delay	Driver instruction delay time	20ms
	Timeout	Driver instruction timeout	1000ms
Speed Cfg (rps)	Start speed	Compressor starting speed	30 rps

NOTE: Additional configuration options are available depending on the inverter driver manufacturer (EU or Carel).

Table 5-8 Additional Inverter Settings (EU)

Menu Screen	Option	Description	Default
Inverter Setting	Keep speed	Speed to maintain during starting period	40 rps
	Min. Lim. speed	Minimum speed limit	27 rps
	Max. Lim. speed	Maximum speed limit	64 rps
	Start Keep Time	Time to maintain “Keep speed” after start	195s
Speed Step Cfg (rps/s)	Incre. Step	Acceleration rate	30 rps/s
	Decre. Step	Deceleration rate	30 rps/s
	Decre. Step. Ser	Maximum deceleration	90 rps/s
Inverter Setting [EU]	Start pressure Diff. Lim	Maximum pressure differential during startup	116.0 psi
	Control rate	EEV control rate	1.2

Table 5-9 Additional Inverter Settings (Carel)

Menu Screen	Option	Description	Default
Start up pressure Differential Control	Max pressure differential	Maximum pressure differential allowed during start up	3 bar
	Equalization mode		EEV Preopening
	Max Equaliz. Time	Maximum equalization time	10s
	EEV Opening	EEV opening percentage during equalization	100%
Start-up failure control	Press difference min. variation	Minimum pressure differential allowed during startup	0 bar
	Control period	Control period	0s
	Restart delay	Restart delay	0s
	Max retry number	Maximum number of restarts	5

Menu Screen	Option	Description	Default
Speed management	Start-by forced speed	Starting speed	0 rps
	Max speed	Maximum speed	64 rps
	Min speed	Minimum speed	27 rps
	Deceleration Rate	Deceleration rate	0 rps/s
	Acceleration rate	Acceleration rate	0 rps/s
	Switch-off rate	Deceleration rate when powering off	0 rps/s
Envelope Control	Speed reduction rate	Deceleration rate	0 rps/s
	Min speed admitted	Minimum speed	0 rps
	Out of Envelope Alarm Timeout	Timeout for out of envelope alarm	180s
	Low pressure diff Alarm Timeout	Timeout for low pressure difference	
Low Ratio management	By EEV Closing	Manage low pressure ratio by closing EEV	No
	By Compressor speed up	Manage low pressure ratio by increasing compressor speed	No
Discharge Gas Control	High Discharge Temp limit	High temperature limit for exhaust gas	
	High discharge temp alarm	Alarm temperature for exhaust gas	
Speed Control Due to Discharge Gas	Action distance	Temperature control range	
	Action pause	Control duration	
	Compressor speed reduction	Compressor speed reduction	
Regulation	Mode	Regulation Mode. Suction Superheat/Discharge Superheat	Suction Superheat
	Discharge temp. probe Compensat. Time	Exhaust temperature probe compensation time	
Discharge Superheat Control	Set point	Super heat set point	
	Offset	Super heat offset	
	Hysteresis	Super heat hysteresis	
Discharge Temperature Control	Set point	Discharge temperature setpoint	
	Offset	Discharge Offset	
	Hysteresis	Discharge Hysteresis	
	Actual work model	Suction Superheat/Discharge Superheat	Suction Superheat

Table 5-10 Parameters in the Alarms Menu

Menu Screen	Option	Description	Default
Alarm Input Logic	Smoke/fire	Smoke/fire alarm logic	N.C
	Generator run	Generator run alarm logic	N.O

Menu Screen	Option	Description	Default
	DC failover	DC failover alarm logic	N.O
	Hydrogen	Hydrogen alarm logic	N.O
	HVAC Alarm 1	HVAC 1 alarm output logic	N.O
Alarm Output Logic	HVAC Alarm 2	HVAC 2 alarm output logic	N.O
	HVAC Alarm 3	HVAC 3 alarm output logic	N.O
High Pressure Alarm	Setpoint	High pressure alarm setpoint	594.7 psi
	Diff	Pressure below setpoint at which the alarm turns off	145 psi
Low pressure alarm	Thresh	Low pressure alarm trigger point	72.5 psi
	Start delay	Alarm delay after compressor starts	30s
	Running delay	Delay before alarm triggers	10s
	Low out delay	Delay before alarm triggers again	60s
	Lim. thresh.	Low pressure at which compressor steps	58 psi
	Lim. hyst.	Low pressure alarm hysteresis	29 psi
Supply fan ovl. alarm	Start delay	Alarm delay after supply fan start	20s
	Running delay	Delay before alarm triggers	10s
Dust detect alarm	Delay time	Delay before alarm triggers	60s
	Retry wait time	Time between dust checks	1 min
	Auto reset time	Alarm will reset if no protection events occur in this interval	1 h
High Supply Temp Alarm	Thresh	Temperature above set point at which alarm triggers	5.4°F
	Start delay	Alarm delay after supply fan start	1 min
	Running delay	Delay before alarm triggers	60s
Damper alarm	Comp. off DT	Alarm delay after compressor stop	2 min
	Close diff	Maximum temperature differential between room and supply temperature when damper is closed	6.5°F
	Open diff	Maximum temperature differential between outdoor and supply temperature when damper is open	6.5°F
	Diff. check T	Time differential between temperature checks	5 min
	Retry time	Time allowed for temperature checks. Alarm will trigger if "Retry number" is exceeded in this interval	60 min
	Retry number	Number of checks before alarms	3
	Alarm delay	Delay before alarm triggers	12 min
Low Temp	Low Temp Alarm Diff	Low room temperature alarm trigger point	34°F

Menu Screen	Option	Description	Default
	Delay time	Delay before alarm triggers	60s
High Temp	High Temp Alarm Diff	High room temperature alarm trigger point. Alarm will trigger if temperature is this much higher than the setpoint	16°F
	Delay time	Delay before alarm triggers	60s
Low Supply temp	Low supply temp	Low supply temperature alarm trigger point	10.8°F
	Delay time	Delay before alarm triggers	20s
Dirty Condenser	Enable Dirty Condenser	Enable dirty condenser alarm	Yes
	Subcool Setpoint	Maximum allowed supercool before triggering alarm	41°F
	Subcool Diff	Temperature above supercool setpoint at which the alarm will restore	1.8°F
	Threshold Set		80%
Generator run	FC limited by Gen.	Disable free cooling during generator run	No
	Comp limited by Gen.	Compressor speed limited by generator run	Yes

5.3 Control Configuration Menu Parameters

NOTE: This menu contains options for the network, setpoints, free cooling, sensors, and input/output logic.

Table 5-11 Parameters in the Network Menu

Menu Screen	Option	Description	Default
Net Config	Total HVACs	Number of HVAC Units	2
	Total Zones	Number of Control Zones	1
	En Zone Temp Sensor	Enable Zone Temp Sensors	No
Network View	Unit ID	Select Unit to View IP Address	1
	View	View Unit IP Address	--
Network Configuration	Unit ID	Select Unit to Change IP Address	1
	New	Change Unit IP Address	--
Network Config	Assign units to each zone and configure operating mode		

Table 5-12 Parameters in the Setpoints Menu

Menu Screen	Option	Description	Default
Zone Configuration	Backup Number	Number of Backup Units in Zone	0
	Setpoint	Zone Setpoint	79°F
	Dead Zone	Zone Deadband	1.8°F
	Comfort Set	Zone Comfort Mode Setpoint	72°F
	Dehum Number	Number of Units in Dehumidification	1
Room Temperature	Cool Band	PID controller dead band	1.8°F

Menu Screen	Option	Description	Default
	Cool Diff	Allowed temperature range for compressor operation	6°F
	Cool Dead	Temperature range around setpoint for compressor operation	2°F
	Backup Diff	Temperature differential above setpoint at which the backup units will come on	8°F
	Backup Offset	Temperature offset at which the backup units will shut off	4°F
Room Temperature PID	Kp	Proportional control setting	25
	Ti	Integral control setting	120
	Td	Derivative control setting	0
Comfort Temperature	Setpoint	Comfort mode setpoint	72°F
	Keep Time	Comfort mode duration	60 min
Heater	Heater Turn On Diff	Temperature range for heater operation	3°F
	Heater Deadband	Temperature below setpoint at which heater turns on	29°F
Dehumidification	Enable	Enable Dehumidification	Disable
	Setpoint	Humidity setpoint	55%
	Diff	Humidity level above setpoint at which dehumidification starts	15%
	Stop diff	Temperature below the setpoint at which the heater will start to dehumidify	11°F
	Start diff	Temperature above heater start point at which heater will stop dehumidifying	6°F
	Heater on delay	Heater start delay during dehumidification	0s
Supply Temperature	Setpoint	Supply temperature setpoint	51.8°F
	Deadband	Supply temperature PID control dead zone	3.6°F
	Limi. High	Supply temperature high limit. Temperature above setpoint at which damper is 100% open.	2.0°F
	Limi. Low	Supply temperature low limit. Temperature below setpoint at which damper is closed.	2.0°F
Supply Temperature PID	Kp	Proportional control setting	33.3
	Ti	Integral control setting	0
	Td	Derivative control setting	0
Setpoint Config	Average Room Temp	Average Multiple Temperature Sensors	No

Table 5-13 Parameters in the Free Cooling Menu

Menu Screen	Option	Description	Default
Free-cooling	Humidity limit	Free cooling humidity limit	Disable
	Max Humidity	Maximum humidity for free cooling	85%
	Humidity Deadband	Humidity below the limit at which free cooling will be re-enabled	5%

	Enable Parti. Freecool	Enable Partial Free Cooling	Disable
	Min. temp. diff. for freecool	Damper will open if the indoor-outdoor temperature difference is larger than this value	3.6°F
	Stop diff	Damper will close if the indoor-outdoor temperature difference is smaller than this value	3.6°F
	Delay	Free cooling delay time	10s
	FC Min	Minimum damper opening percentage	0.0%
Additional function	Sea-side Mode	Enable free cooling only at high indoor temperatures	Disable
	Dust detect	Enable dust detection	Enable
	Emergency ventilation enable	Enable emergency ventilation	Enable
	Setpoint	Temperature above setpoint at which emergency ventilation will activate	14°F
	Diff	Temperature below emergency ventilation setpoint at which emergency ventilation will deactivate	9°F
	Force Comp. Stop for FC	Force compressor to stop during free cooling	Force Stop

Table 5-14 Parameters in the Sensors Menu

Note: Parameters in gray can only be accessed by connecting a PGD to the unit or via the html interface.

Menu Screen	Option	Description	Default
Sensor Settings	Humidity Min Value	Minimum allowed humidity value	20%
	Humidity Max Value	Maximum allowed humidity value	150%
Sensor Settings (Unit Only)	HP min. value	Minimum allowed high pressure sensor value	0 psi
	HP max. value	Maximum allowed high pressure sensor value	652.7 psi
	LP min. value	Minimum allowed low pressure sensor value	14.5 psi
	LP max. value	Maximum allowed low pressure sensor value	514.9 psi
Sensor Offset	Outdoor temp	Outdoor temperature sensor offset	0°F
	Room temp	Room temperature sensor offset	0°F
	Outdoor hum	Outdoor humidity sensor offset	0%
Sensor Offset (Unit Only)	Supply temp	Supply temperature offset	0°F
	Room temp	Room temperature sensor offset	0°F
	Outdoor temp	Outdoor temperature sensor offset	0°F
	Dscg temp	Compressor discharge temperature sensor offset	0°F
	Suct. press	Suction pressure sensor offset	0 psi
	Cond. press	Condensing pressure sensor offset	0 psi
	Suct. temp	Suction temperature sensor offset	0°F
	Cond. temp	Condensing temperature sensor offset	0°F
	Filter air pressure	Filter air pressure sensor offset	0 psi

Table 5-15 Parameters in the I/O Logic Menu

Menu Screen	Option	Description	Default
Component Logic	Exhaust Damper	Exhaust Damper Alarm Logic	N.O
Component Output logic (unit only)	Comp	Compressor alarm output logic	N.O

5.4 Accessing the System Menu

Table 5-16 Parameters in the System Menu

Menu Screen	Option	Description
Date/Time	Format	Date Format
	Date	System Date
	Hour	System Time (24 hr clock)
	Day	Day of the week
Serial Ports	Baudrate	Change baud rate
Pwd Change	Change Password	Change system passwords
Initialization	Clear alarm logs	Change "No" to "Yes" to clear logs
	Clear AutoReset Counters	Change "No" to "Yes" to clear counters
	Wipe retain mem	Wipe memory
	Wipe NVRAM	Wipe storage
	Wipe both	Wipe memory and storage

5.5 Accessing the Debug and Hardware Configuration Menus

The Debug and Hardware Configuration Menus contain configuration options for all controller modules. Settings changed here from the controller box will not carry over to the individual units. No password is required to access these options.

Note: The Debug Menu should not be accessed outside of initial startup or system update unless directed by AIRSYS Support or the site technician. To enter the Debug Menu, press Up and Down at the same time from the main screen.

Table 5-17 Debug Menu Options

Menu Screen	Option	Description
Master/HVAC Select	Master/HVAC	Select between Master and HVAC controller operation
Conversion	Unit Conversion	Change between different unit systems
Operation Mode (Unit Only)	Operation Mode	Select between normal and fixed speed operation
Work alone mode	Work alone mode	Set up unit for operation without an ASMUC.6 controller

To enter the Hardware Configuration Menu, hold Alarm and Enter at the same time until the menu is displayed.

Table 5-18 Hardware Configuration Menu Options

Menu Screen	Option	Description
Information	PCO Info	Control software information
	I/O Info	HW and SW version information
	Memory Info	System RAM Usage
	pLAN Info	System pLAN address
	Filesystem Info	System Storage Info
	Tasks Info	System Tasks Information
	Application Info	Current system status
	Built In Info	Built In Info
Settings	Password	Change password
	Connections	Allow USB, PC, and pCO disk connections
	pLAN pCO address	Change pCO address
	Clock	Change time or sync to server
	TCP/IP Settings	Change IP address and settings
Application	Application settings	Reboot controller and controller OS options
Upgrade	Upgrade	Upgrade OS
Logger	Logs	Export, wipe, restart system logs
Diagnostics	System Logs	View system logs

6. Preventative Maintenance

Table 6-1 provides PM guidelines that should be followed for optimal performance. Following these guidelines will help avoid serious damage to components and expensive repairs by skilled personnel.

Table 6-1 Preventative Maintenance Schedule

Task	Recommended Frequency	Comments
Inspect all wiring for signs of wear	Based on local conditions	More frequently in areas with active rodent or insect populations that can damage wiring
Check general operations	12 months	Perform the Step-Test
Inspect all hardware for “snug” connection	12 months	Make note of any loose hardware so it can be checked again at next scheduled PM
Air filter inspection/cleaning and replacement if needed	Based on local conditions	Depends on the amount and frequency of airborne particulates in the area
Inspect and clean condenser coil	Based on local conditions	More frequently in areas that experience excessive airborne particulates that will collect on the condenser coil
Inspect drain pipes (condenser and evaporator)	12 months	
Physical Inspection of Air Damper	12 months	



Danger. Stop the machine and remove the power supply from the equipment before performing maintenance operations.



Important. All PM should be performed by an AIRSYS Authorized Service Technician (AAST) to ensure that the manufacturer’s warranty is preserved.

6.1 General Operation Check

It is a good idea to compare the operation of the equipment with the results of the previous inspection. Any differences in operating characteristics can then be easily identified.

A detailed and periodic visual inspection of the equipment and a general cleaning are both important to ensure good operation. Before beginning the PM steps, the general system status should be verified by looking at the areas outlined in this section.

6.1.1 Check Main Voltage


Check that:

- The main voltage is within $\pm 15\%$ of the rated voltage required by the machine.
- The DC voltage is in normal range, if applicable. (36 -57VDC)
- The main electrical supply cable and the terminals, including the user terminal cable, are correctly connected.
- All cables are secured to the system.

6.1.2 Check Wiring and Components

For wiring and components, perform a preliminary check to verify the system is functional:

- Check that the system has been installed correctly.
- Check that the wiring cable sections meet current capacity. Report any incorrect mounting and setting to the AAST who installed the system so that the necessary modifications can be made.
- Check that the grounding cables have been installed in the controller box and unit as shown in the graphic.



6.1.3 Perform the Step-Test

The purpose of this test is to simulate real operation without damaging components due to incorrect operation or protection failures.

Use the step test to check that the relays, breakers, and components work normally. For details, see “Execute the Step-Test” on Page 60.

6.1.4 Replace Air Filter

A dirty air filter reduces the air volume and the system capacity. This problem can be avoided by regularly cleaning or replacing filters. The frequency at which filters must be checked depends on the amount of dust in the environment. If the filters are frequently very dirty, the frequency of checks and maintenance should be increased.

6.1.5 Clean the Preliminary Air Filter

The preliminary air filter can become clogged with dust and leaves or other debris after a period of use and should be cleaned with water or compressed air.

6.1.6 Inspect and Clean Condenser Coils

During times of peak usage, the condensing coils must be able to offer maximum thermal exchange. Debris such as paper, dead leaves, and dust can be sucked in around the coils, reducing the thermal exchange rate. Dirty condenser coils may trigger the high-pressure switch and cause the compressor to lock out.

Remove any objects from the coil which may have accumulated and wash the system with water and commercial coil cleaner. The coil should be inspected more frequently if the environment experiences seasons of high dust or falling leaves.

6.1.7 Inspect and Clean the Drain Pipes (Both Evaporator and Condenser Drain Pipes)

To avoid water overflow, ensure that the system has proper drainage discharges. The pipe and outflow should be completely free of any obstructions. If necessary, clean the drain and outflow area.

6.1.8 Physical Inspection of the Damper

The air damper is a critical element in the WPU. If it does not function normally, the free cooling function will fail. This can be avoided by periodically and regularly checking the following:

- Check if the damper can fully open and close via the manual override
- Check if the nuts are properly tightened, as shown in the following images



6.2 Operation Checklist

If a problem with the system is experienced, use this checklist to verify the system and determine the root cause. Keep these records for future inspections.

Address: _____ Site No.: _____ Date: _____	
Unit Factory Number: _____ (refer to the unit name plate)	
Check Items	✓ or ✗
Step-Test or Manual Operation	
Verify WPU supply fan(s) work normally	
Verify WPU heater work normally	
Verify WPU compressor works normally At the same time, check if the WPU condenser fan works normally.	
Verify WPU free cooling is working	
Record these values using pressure gauges, built-in sensors, or multi-meter readings	
Outdoor Temperature: _____ Indoor Temperature: _____	
The WPU suction pressure R410a system, normal range: 8-12Bar/116-174PSI	Bar/PSI
The WPU discharge pressure R410a system normal range: 25-30Bar/362.5-435PSI	Bar/PSI
The WPU current of the compressor (refer to nameplate)	Amp
The WPU current of the supply fan (refer to nameplate)	Amp
The WPU input voltage	VAC

7. System Update

Both the ASMUC.6 controller and the P-CRACs can gain additional functions and improvements by updating the control software and operating system. All required software and upgrade packages will be provided by AIRSYS. To request an update package, contact AIRSYS Support at support@air-sys.us.

Updates can be performed via the web interface or the USB connection. A microUSB to USB cable is required to perform the update.

7.1 Local Software Update:

Required Equipment

1. Upgrade Files. Download the latest software from <https://support.airsysnorthamerica.com/>. Search for “ASMUC Software Upgrade”.
2. Laptop/PC. A computer is required to upload the update files.
3. MicroUSB cable.



Figure 7-1 microUSB Cable

7.1.1 Step 1: Upgrade HVAC Units

Note: An external display must be connected to the unit being upgraded. If an extra display is unavailable, the one installed in the controller can be detached using the instructions below. Skip a-d if an external display is available.

1. Download and unzip both the upgrade and HTTP files.
2. Open the controller box and disconnect the plug on the rear of the display.
3. Using a flathead screwdriver or similar tool, remove the PGD frame. See Figure 7-2.
4. Remove the screws securing the PGD to the ASMUC door.
5. Install the display on the HVAC unit.



Figure 7-2 Detach Display Frame

6. Connect the computer to the micro USB port on the controller board inside the unit. The controller should become visible as external storage “USB Drive” on the PC.
7. Copy the AP1 file to the “Upgrade” folder.
8. Copy the HTTP folder to the root directory (“USB Drive”) and overwrite the existing files.




Figure 7-3 Controller Board




Figure 7-4 Upgrade Folder

9. Disconnect the USB cable from the controller board inside the unit. The upgrade process will automatically start.
10. Once the upgrade is complete, the screen will display “Upload successful” and return to the main screen. This may take up to 5 minutes.
11. Repeat process d-g for all HVAC units to be upgraded.
12. Reinstall the display on the ASMUC.

Step 2: Save Controller Setting

The software upgrade procedure will reset all settings to factory defaults. Some settings must be manually reconfigured. Complete the following steps from the ASMUC.

1. Press Prg and enter the default password (0004). Press Enter.

Note: If password has been changed from factory default, consult the facility manager for correct password.

2. Press Up or Down to reach “Control Config” and press Enter.
3. Press Enter at “Network”
4. Record all network settings (a-d). Press Down to access each individual screen.

- Total # of HVAC and Total # of Zones

```

SNetwork configuration
Net Conf19:

Total HVACs:          5
Total Zones:          2
En Zone Temp Sensor: Yes
Control Type: Manu.
    
```

- IP address of all connected HVAC units (Press Enter and use the Up and Down buttons to cycle through units. Press Enter to display the IP of each unit.)

```

Network View
Network
UnitID:              1
IP address:
View: 192.168.137.15
    
```

- Zone assignment (which units are assigned to which zones).

```

SNetwork configuration
Network Conf19:      5
Unit#:Zone/ Status
ID 01: 1 / Rotate
ID 02: 1 / Rotate
ID 03: 1 / Rotate
ID 04: 2 / Rotate
    
```

- Model numbers of connected units.

```

SNetwork configuration
HVAC Model Setting
ID01:11V1C3MR410AAC 2
ID02:11V1C3MR410AAC 2
    
```

5. (Optional) Record any other settings, such as temperature setpoint, that are to be maintained.

7.1.2 Step 3: Upgrade Controller (ASMUC)

Connect the computer to the micro USB port on the controller board inside the ASMUC. The controller should become visible as external storage “USB Drive” on the PC.

1. Connect the computer to the micro USB port on the controller board inside the ASMUC. The controller should become visible as external storage “USB Drive” on the PC.
2. Copy the AP1 file to the “Upgrade” folder.
3. Copy the HTTP folder to the root directory and overwrite the existing files.
4. Disconnect the USB cable from the controller. The upgrade process will automatically start.
5. Once the upgrade is complete, the screen will display “Upload successful” and return to the main screen. This may take up to 5 minutes.
6. Power cycle the controller by turning off the breaker and turning back on after a few seconds.

7.1.3 Step 4: Reload Saved Parameters on Controller

1. Pressure Up and Down together.
2. In the “Master/HVAC select” screen, select “Master Controller” and press Enter.
3. Press Esc.
4. Press Prg and enter the default password (0004). Press Enter.
5. Press Up or Down to reach “Control Config” and press Enter.
6. Press Enter at “Network”
7. Re-enter the saved information (a-d)
 - Total # of HVAC and Total # of Zones
 - IP address of all connected HVAC units
 - Zone assignment, which units are assigned to which zones.
 - Model number of connected units
8. Re-enter any other setting that has been manually saved.

7.1.4 Step 5: Restore and Verify Controller Operation

1. Hold Esc until the main screen is displayed.
2. Press Down until an info icon (i) is displayed in the bottom right corner and press Enter.
3. If the controller has re-established communication with the units, ON or OFF status should be displayed for every unit.




Figure 7-5 Network Status

7.2 Remote Software Upgrade:

Required Equipment

1. Upgrade Files. Download the latest software from <https://support.airsysnorthamerica.com/>. Search for “ASMUC Software Download”.
2. PC/Laptop, needed for remote connection to controller.
3. Remote IP/HTTP connection to all HVAC units and multi-unit controller to be upgraded.
4. If upgrading webpages: FTP software/connection.

Step 1: Upgrade HVAC units

1. Download and unzip both the HTTP and the upgrade files.
2. Navigate to the IP address of the HVAC unit (not the multi-unit controller).
 - If unsure, navigate to “Controller Interface” tab. Master Controller/HVAC status will be displayed on the main page




Figure 7-6 Master/HVAC Status

3. Select “Upgrade” tab on the left.
4. Click “Choose File” under “C.pCO AP1 Upgrade” and select the previously downloaded AP1 file.




Figure 7-7 File Selection Screen

5. Click "Upgrade AP1 to c.pCO", the upgrade process will start.
6. Once the upgrade is complete, the status will display "Upload successful". This may take up to 5 minutes.
7. Repeat steps 1-5 for all HVAC units.

Step 2: Save Controller Settings

The software upgrade procedure will reset all settings to factory defaults. Some settings must be manually reconfigured. Complete the following steps using the ASMUC web interface.

1. Navigate to the IP address of the multi-unit controller.
 - If unsure, navigate to “Controller Interface” tab. Master Controller/HVAC status will be displayed on the main page.
2. Navigate to the “Controller Interface” tab.
3. Press Prg (Ⓞ) and enter the default password (0004). Press Enter.
4. Press Up or Down to reach “Control Config” and press Enter.

Press Enter at “Network”.

5. Record all network settings (i-iv). Press Down to access each individual screen.
 - Total # of HVAC and Total # of Zones

```

Network configuration
Net  Conf19:

Total HVACs:           5
Total Zones:          20
En Zone Temp Sensor:  Yes
Control Type: Manu.
  
```

- IP address of all connected HVAC units (Press Enter and use the Up and Down buttons to cycle through units. Press Enter to display the IP of each unit.)

```

Network View
Network
UnitID:           1
IP address:

View:  192.168.137. 15
  
```

- Zone assignment (which units are assigned to which zones).

```

SNetwork configuration
Network Conf 19:      5
Unit#:Zone/  Status
ID 01:  1 / Rotate
ID 02:  1 / Rotate
ID 03:  1 / Rotate
ID 04:  2 / Rotate
    
```

- Model numbers of connected units.

```

SNetwork configuration
HVAC Model Setting
ID01:11U1C3MR410AAC 2
ID02:11U1C3MR410AAC 2
    
```

6. (Optional) Write down any other settings, such as temperature setpoint, that need to be carried over.

Step 3: Upgrade Controller (ASMUC)

1. Select “Upgrade” tab on the left.
2. Click “Choose File” under “C.pCO AP1 Upgrade” and select the previously downloaded AP1 file.



3. Click “Upgrade AP1 to c.pCO”, the upgrade process will start.
4. Once the upgrade is complete, the status will display “Upload successful”. This may take up to 5 minutes.


Step 4: Reload Saved Parameters on Controller

1. Navigate to the “Controller Interface” tab.
2. Press Up and Down together.
3. In the “Master/HVAC select” screen, select “Master Controller” and press Enter.
4. Press Prg and enter the default password (0004). Press Enter.
5. Press Up or Down to reach “Control Config” and press Enter.
6. Press Enter at “Network”.

7. Re-enter the saved information:
 - Total HVAC and Total Zones.
 - IP address of all connected HVAC units.
 - Zone assignment, which units are assigned to which zones.
 - Model number of connected units.
8. Re-enter any other settings that have been manually saved.

Step 5: Restore and Verify Controller Operation

1. Hold Esc until the main screen is displayed.
2. Press Prg and enter the password (0004). Press Enter
3. Select System and press Enter.
4. Press Down until the cursor is over "Initialization" and press Enter.
5. Press Down until screen shows "Reboot System".



6. Press Down until an info. icon (i) is displayed in the bottom right corner and press Enter.
7. If the controller has re-established communication with the units, ON or OFF status should be displayed for every unit.




Figure 7-8 Network Status

Step 6: (Optional) Update HTTP files

Note: Updated webpages may change the look of the HTML page and may include more information not previously available. Updating will not affect system operation.

1. Use a built-in FTP client or an FTP application such as FileZilla (recommended open source client) to establish connection to the IP of the controller.
 - Depending on network conditions and how many connection the controller has, the Time Out setting may need to be adjusted to 40 seconds or more. To change timeout in Filezilla, go to Edit->Setting->Connection.
 - Leave Username and password blank. Use port 21 if prompted.
2. Replace/overwrite HTTP folder under root directory with new HTTP folder included in the update file. The transfer may take up to 10 minutes.
3. Disconnect FTP server. The browser cache may need to be cleared for the webpage to display the correct version.

8. Spare Parts

For all part requests, please contact:

AIRSYS Cooling Technologies

Web: <http://airsysnorthamerica.com>

Email: support@air-sys.us

Phone: 855-874-538




Figure 8-1 40V1R3 Part Identification

Table 8-1 40V1R3 Part Identification

Number	Part Name	Number	Part Name	Number	Part Name
1	Drain Pan Top Assembly	18	Invertor Driver	35	Side Panel, Right
2	Left Rear Corner Column Assembly	19	Condenser Fan Bracket	36	Right Front Corner Column Assembly
3	Install Angle Iron	20	Condenser Fan	37	Front Center Column Assembly-2
4	Left Partition Assembly	21	Fresh Air Cover	38	Condenser Right Side Assembly
5	Condenser Left Side Assembly	22	Preliminary Filter	39	Right Partition Assembly
6	Side Panel, Left	23	Fresh Supply Grille	40	Right Rear Corner Column Assembly
7	Supply Air Partition Assembly	24	AFPD Sensor	41	Top Panel, Side
8	Base Assembly	25	Humidity Sensor	42	Top Panel, Middle
9	Left Front Corner Column Assembly	26	Return Air Damper Cover	43	Return Air Panel Assembly
10	Front Center Column Assembly-1	27	Fresh Air Damper Bracket	44	Return Air Flange
11	Bottom Drain Pan Assembly	28	Discharge Air Damper Bracket	45	Rear Panel, Middle
12	Supply Fan	29	Fresh Air Damper Actuator	46	Supply Air Flange
13	Supply Fan Support	30	Discharge Air Damper Actuator	47	Supply Air Panel Assembly
14	Supply Fan Bracket	31	Return Air Damper Actuator	48	Rear Center Column Assembly
15	Electrical Heater	32	Electrical Box	49	Evaporator
16	Supply Fan Maintenance Cover	33	Compressor	50	Return Air Partition Assembly
17	Pressure Differential Sensor	34	Air Filter		




Figure 8-2 40V1L3 Part Identification

Table 8-2 40V1L3 Part Identification

Number	Part Name	Number	Part Name	Number	Part Name
1	Invertor Drive	15	Back Panel, Middle	29	Electrical Components
2	Invertor Cover	16	Evaporator	30	Compressor
3	Pressure Differential Sensor	17	Air Return Flange	31	Fresh Air Damper Actuator
4	Junction Box	18	Air Return Panel Assembly	32	Fresh Air Damper Weldment
5	Supply Fan	19	Air Discharge Damper	33	Condenser Fan Mounting Plate
6	Supply Fan Bracket Assembly	20	Air Return Damper	34	Condenser Fan
7	Side Panel, Right	21	Drain Pan Top Assembly	35	Drain Pump Assembly
8	Condenser, Right	22	Install Angle Iron	36	Rain Cover
9	Air Filter	23	Side Panel-Left	37	Preliminary Filter, G2
10	Air Supply Panel Assembly	24	Condenser-Left	38	Fresh Air Grille
11	Top Panel Assembly, Right	25	Lifting Panel Assembly	39	AFPD
12	Top Panel-Middle	26	Pipeline Assembly	40	Condenser Fan Mounting Plate-2
13	Top Panel Assembly, Left	27	Base Cover Plate Assembly	41	Supply Fan Maintenance Cover
14	Air Supply Flange	28	Base Assembly	42	Electrical Heater












Figure 8-3 20V1R1 Part Identification


Table 8-3 20V1R1 Part Identification

Number	Part Name	Number	Part Name	Number	Part Name
1	Base Plate Weldment	15	Air Filter	29	Middle Back Panel
2	Pipeline Assembly	16	Right Panel-1	30	Supply Air Panel Weldment
3	Inductor and Cover	17	Condenser-Right	31	Supply Air Flange
4	Invertor and Invertor Cover	18	Discharge Damper	32	Draining Pan Weldment
5	Drain Pump	19	Right Panel-2	33	Evaporator
6	Condenser Fan Mounting Plate	20	Electrical Panel	34	Supply Air Partition
7	Condenser fan	21	Fresh Air Damper	35	Supply Fan Bracket Weldment
8	Front Middle Panel	22	Top Panel Weldment-1	36	Supply Fan
9	Condenser Fan Mounting Plate-2	23	Top Panel Weldment-2	37	Left Panel-2
10	Compressor	24	Return Air Damper	38	Electrical Heater
11	Fresh Air Partition Weldment	25	Junction Box	39	Left Panel-1
12	Pressure Differential Switch	26	Return Air Partition Weldment	40	Condenser-Left
13	AFPD	27	Return Air Flange	41	Bottom Plate Cover
14	Preliminary Filter	28	Middle Partition Weldment	42	Bottom Plate Cover Weldment


Appendix A: Air Flange Drawing



Appendix B: Wiring Diagrams



Note:
 1. KBAK-W3 power protector FV, the factory default rated voltage is 220V. All over-voltage (U1105-242V (no) setting position 61%), AL2 under-voltage (U555-167V (no) setting position 62 X), the default delay is 0.1S;
 2. The power protector switch setting SW1=OFF, SW2=ON, SW3=OFF, SW4=OFF.




Note:
 1. FA input '41', had been short with line 5.


Wiring Diagram

Models
 20V1R1MR410AAC
 20V1L1MR410AAC

NO.	Mark	Name	NO.	Mark	Name
01	FV	Power protector	26	QF5	Compressor fan fan relay
02	FN	Fan overload alarm	28	SA3	Condensate fan overload
03	YED	Exhaust damper	27	SW5	Exhaust fan relay
04	YED	Exhaust damper	16	SW4	Exhaust fan relay
05	YED	Exhaust damper	19	SW3	Exhaust fan relay
06	YED	Exhaust damper	20	SW2	Exhaust fan relay
07	YED	Exhaust damper	21	SW1	Exhaust fan relay
08	YED	Exhaust damper	22	SW0	Exhaust fan relay
09	YED	Exhaust damper	23	SW0	Exhaust fan relay
10	YED	Exhaust damper	24	SW0	Exhaust fan relay
11	YED	Exhaust damper	25	SW0	Exhaust fan relay
12	YED	Exhaust damper	26	SW0	Exhaust fan relay
13	YED	Exhaust damper	27	SW0	Exhaust fan relay
14	YED	Exhaust damper	28	SW0	Exhaust fan relay
15	YED	Exhaust damper	29	SW0	Exhaust fan relay
16	YED	Exhaust damper	30	SW0	Exhaust fan relay
17	YED	Exhaust damper	31	SW0	Exhaust fan relay
18	YED	Exhaust damper	32	SW0	Exhaust fan relay
19	YED	Exhaust damper	33	SW0	Exhaust fan relay
20	YED	Exhaust damper	34	SW0	Exhaust fan relay
21	YED	Exhaust damper	35	SW0	Exhaust fan relay
22	YED	Exhaust damper	36	SW0	Exhaust fan relay
23	YED	Exhaust damper	37	SW0	Exhaust fan relay
24	YED	Exhaust damper	38	SW0	Exhaust fan relay




- Note: 1. KT1 Model: HFGS3AZ2-1-RD24, 5 speed time range adjustment knob: 1m-30m - Factory setting 5m.
 2. FV Setting value set
 2.1 Rated voltage setting 230V.
 2.2 Over voltage setting OV(U)/+15%.
 2.3 Delay range setting +0.1S.
 2.4 Unbalance range setting Asm+8%.




- Note: 1. FA input '41', had been short with line 5.

NO.	Mark	Name	NO.	Mark	Name
01	FV	Power contact	25	FA	Temperature switch for heating
02	FA	Flue Smoke alarm	26	ST6	Condenser temperature
03	YE3	Exhaust damper	27	ST5	Exhaust air temperature
04	YE2	Bypass damper	28	ST4	Evaporator temperature
05	YE1	Free cooling damper	29	ST3	Outdoor temperature
06	YE	Free cooling damper	30	ST2	Supply temperature
07	MF1/MF2	Condenser fan	31	ST1	Indoor temperature
08	MF3	Evaporator fan	32	ST0	On-line normal display (on/line)
09	HE1	Heater	33	CP100	Control board
10	MC1	Indoor coil sensor	34	KA2	Condenser expansion board
11	MC2	Outdoor coil sensor	35	SM1	Static pressure Controller
12	HE	Electric heater	36	KA1	Relay
13	PU3P	Condensate Drain Pump	37	OP1	Inverter breaker
14	HE3	High pressure switch	38	OP2/OP3	Condenser fan breaker
15	SA1	High pressure Transducer	39	OP3	Evaporator fan breaker
16	ST4	Low pressure Transducer	40	OP4	Exhaust fan breaker
17	EVD	Exhaust damper valve	41	OP5	Exhaust fan breaker
18	XT1	Terminal board	42	UPA	Water pump control breaker
19	W66	Duct sensor	43	UPB	Leakage valve
20	SM1	Static pressure sensor	44	UPC	Switch power supply
21	SM2	Exhaust air sensor for Filter block	45	EC1	Transformer
22	FA	Flue Smoke alarm	46	SW1	Unit on/off protection switch
23	XT1	Line bus relay, only for 300v series	47	SW2	Water pump start running switch
24	SW3	Water pump stop switch	48	VE4	Fire damper



- Note: 1. KT1 Model: HFGS3AZ2-1-RD24, 5 speed time range adjustment knob: 1m-30m - Factory setting 5m.
 2. FV Setting value set
 2.1 Rated voltage setting 480V.
 2.2 Over voltage setting OV(U)/+15%.
 2.3 Delay range setting +0.1S.
 2.4 Unbalance range setting Asm+8%.



- Note: 1. FA input '41', had been short with line 5.
 2. Dc reactor interface on the side of the frequency converter. When no reactor is selected, short-circuit terminal is used directly.

NO.	Mark	Name	NO.	Mark	Name
01	FV	Power contact	25	FA	Temperature switch for heating
02	FA	Flue Smoke alarm	26	ST6	Condenser temperature
03	YE3	Exhaust damper	27	ST5	Exhaust air temperature
04	YE2	Bypass damper	28	ST4	Evaporator temperature
05	YE1	Free cooling damper	29	ST3	Outdoor temperature
06	YE	Free cooling damper	30	ST2	Supply temperature
07	MF1/MF2	Condenser fan	31	ST1	Indoor temperature
08	MF3	Evaporator fan	32	ST0	On-line normal display (on/line)
09	HE1	Heater	33	CP100	Control board
10	MC1	Indoor coil sensor	34	KA2	Condenser expansion board
11	MC2	Outdoor coil sensor	35	SM1	Static pressure Controller
12	HE	Electric heater	36	KA1	Relay
13	PU3P	Condensate Drain Pump	37	OP1	Inverter breaker
14	HE3	High pressure switch	38	OP2/OP3	Condenser fan breaker
15	SA1	High pressure Transducer	39	OP3	Evaporator fan breaker
16	ST4	Low pressure Transducer	40	OP4	Exhaust fan breaker
17	EVD	Exhaust damper valve	41	OP5	Exhaust fan breaker
18	XT1	Terminal board	42	UPA	Water pump control breaker
19	W66	Duct sensor	43	UPB	Leakage valve
20	SM1	Static pressure sensor	44	UPC	Switch power supply
21	SM2	Exhaust air sensor for Filter block	45	EC1	Transformer
22	FA	Flue Smoke alarm	46	SW1	Unit on/off protection switch
23	XT1	Line bus relay, only for 300v series	47	SW2	Water pump start running switch
24	SW3	Water pump stop switch	48	VE4	Fire damper

List of Tables

Table 1-1 Packaging Symbols	7
Table 1-2 Packaging Symbols	9
Table 3-1 AIRSYS Provided Materials	18
Table 3-2 Installer Supplied Materials.....	19
Table 3-3 UniCool Edge Electrical Ratings	20
Table 3-4 Controller Electrical Ratings	20
Table 3-5 Installation Clearances	25
Table 3-6 Dimensions and Weight by Model Number	25
Table 3-7 Key Components in the Controller Box Assembly	37
Table 3-8 Step Test	52
Table 4-1 PGD Button Actions	59
Table 4-2 System Statuses	61
Table 4-3 Controller Info Menu	64
Table 4-4 Unit Info Menu	65
Table 4-5 Step Test	69
Table 4-6 Alarm Descriptions.....	70
Table 5-1 Parameters in the Supply Fan Menu	80
Table 5-2 Parameters in the Supply Fan Menu	81
Table 5-3 Parameters in the EEV Menu	81
Table 5-4 EU EEV Configuration Options	81
Table 5-5 Carel EEV Configuration Options	82
Table 5-6 Parameters in the Compressor Menu	83
Table 5-7 Parameters in the Inverter Menu	84
Table 5-8 Additional Inverter Settings (EU)	84
Table 5-9 Additional Inverter Settings (Carel).....	84
Table 5-10 Parameters in the Alarms Menu	85
Table 5-11 Parameters in the Network Menu	87
Table 5-12 Parameters in the Setpoints Menu	87
Table 5-13 Parameters in the Free Cooling Menu	88
Table 5-14 Parameters in the Sensors Menu	90
Table 5-15 Parameters in the I/O Logic Menu	90
Table 5-16 Parameters in the System Menu	91
Table 5-17 Debug Menu Options.....	91
Table 5-18 Hardware Configuration Menu Options	93
Table 6-1 Preventative Maintenance Schedule	95
Table 8-1 40V1R3 Part Identification	112

List of Figures

Figure 1-1 Model Number	8
Figure 2-1 Mechanical Cooling Mode-Diagram Shown as Right Supply	11
Figure 2-2 Free Cooling Mode-Diagram Shown as Right Supply	11
Figure 2-3 Mechanical and Free Cooling Mode-Diagram Shown as Right Supply	12
Figure 3-1 Physical Dimension (40V1R3).....	21
Figure 3-2 Openings and Holes in the Wall (40V1R3).....	26
Figure 3-3 Install CR-Sponge	28
Figure 3-4 Install Supply/Return Air Frame.....	28
Figure 3-5 Install Weather Stripping	29
Figure 3-6 Remove Wooden Pallet.....	30
Figure 3-7 Lift the Unit	30
Figure 3-8 Inclination of Mounted P-CRAC.....	33
Figure 3-9 Seal the Joints Between P-CRAC and Wall	34
Figure 3-10 Remove Compressor Brackets.....	35
Figure 3-11 Controller Box Dimensions	36
Figure 3-12 ST3 Through Wall.....	37
Figure 3-13 ST3 Through Bottom of Controller Box.....	38
Figure 3-14 Ensure No Leakage.....	38
Figure 3-15 Position the Humidity Sensor	39
Figure 3-16 Position the Indoor Temperature Sensor.....	39
Figure 3-17 Phase Monitor	42
Figure 3-18 PGD Cable	42
Figure 3-19 Prime Power Connections	43
Figure 3-20 Main Power Wiring and Filter/Smoke Alarm Wiring.....	44
Figure 3-21 Unit Grounding	44
Figure 3-22 P-CRAC Phase Monitor.....	46
Figure 3-23 IP Configuration.....	47
Figure 3-24 Remove PDG Frame	48
Figure 3-25 Remove Screws of PGD.....	48
Figure 3-26 Zone Configuration Screen.....	50
Figure 3-27 On/Off Screen.....	51
Figure 3-28 Verify the Main Setpoint	54
Figure 3-29 Enable SNMP	55
Figure 4-1 PGD User Interface	59
Figure 4-2 Main Screen	60
Figure 4-3 On/Off Screen.....	61
Figure 4-4 Setpoint Screen	62
Figure 4-5 Comfort Mode Screen	63
Figure 4-6 Unit Selection Screen.....	63

Figure 4-7 HVAC ID Select Screen.....	65
Figure 4-8 Program Menu Selection Screen.....	68
Figure 4-9 Step Test Selection Screen	69
Figure 4-10 Alarm Logs	72
Figure 4-11 Clear Alarm History	73
Figure 4-12 Hardware Configuration Menu.....	73
Figure 4-13 Factory Reset Screen.....	75
Figure 4-14 Set the Master	75
Figure 4-15 Heater Operation Logic	77
Figure 4-16 Dehumidification Logic	77
Figure 7-1 microUSB Cable	100
Figure 7-2 Detach Display Frame	101
Figure 7-3 Controller Board	101
Figure 7-4 Upgrade Folder.....	101
Figure 7-5 Network Status	104
Figure 7-6 Master/HVAC Status	104
Figure 7-7 File Selection Screen.....	105
Figure 7-8 Network Status	108
Figure 8-1 40V1R3 Part Identification.....	111



AIRSYS Global Subsidiaries

Contact:

Headquarter

AIRSYS Cooling Technologies, Inc

Add: 7820 Reidville Rd. Greer, SC 29651 , USA
Tel: +1 (855) 874 5380
Email: sales@air-sys.us

AIRSYS (UK) Ltd.

Add: 245 Europa Boulevard, Warrington, UK. WA5 7TN
Tel: +44 (0) 1925 377 272
Call Centre: +44(0)8456099950
Email: enquiries@air-sys.uk

AIRSYS Brasil Ltda.

Add: Av. Moaci, 395 Conj 35/36 04083-000 – Planalto Paulista
SAO PAULO – SP
Tel: +55 (11) 25976817 / +55 (11) 21585560
Email: airsys-brasil@air-sys.com.br

AIRSYS Deutschland GmbH

Add: Feringastr. 6, 85774 Unterföhring / München, Germany
Tel: +49 89 9921 6510
Email: anfragen@air-sys.eu

AIRSYS Refrigeration Engineering Technology (Beijing) Co., Ltd.

Add: 10th floor, Hongkun Shengtong building, 19, Ping Guo Yuan Xi Xiao Jie, Shijingshan, Beijing, China 100043
Tel: +86(0)10 68656161
Email: airsys@air-sys.com

Gu'an AIRSYS Environment Technology Company Ltd.

Add: 25, Dongfang Street, Gu'an Industry Park, Langfang City, Hebei Province, China
Tel: +86(0)10 68656161

Shanghai AIRSERVE HVAC System Service Co., Ltd.

Add: Room 1701, Xinda building, No. 322 Xianxia Road, Changning District, Shanghai, China 200336
Tel: +86(0)21 62452626 Fax: +86 (0)21 6245962

AIRSYS Singapore Pte. Ltd

Add: 50, Tagore Lane Entrepreneur Centre, #03-04 (F), Singapore 787494
Tel: +65 64991850
Fax: +65 68416301
Email: sales@air-sys.sg

AIRSYS Philippines Corporation

Add: Unit 1603 16th Floor 139 Corporate Centre Building Valero St. Salcedo Village Bel-Air 1209 Makati, Philippines
Tel: +63 84581047
Fax: +63 88470496
Email: sales@air-sys.sg

AIRSYS Malaysia Sdn. Bhd.

NO. 7-1, Jalan 109F, Plaza Danau 2, Taman Danau Desa, 58100 Kuala Lumpur Wilayah Persekutuan Malaysia
Tel: +60 3 7982 2010
Fax: +60 3 7980 1242
Email: sales@air-sys.sg

AIRSYS Australia Sales Office

Add: PO BOX 1088, Flagstaff Hill, SA, 5159, Australia
Tel: +61 479151080
Email: sales@air-sys.sg

Product design and specification subject to change without prior notice

